

ENGINE AND EMISSION CONTROL

CONTENTS

(Continued)

AUTO-CRUISE CONTROL SYSTEM	6	CATALYTIC CONVERTER	46	
.....	6	General Information	46	
AUTO-CRUISE CONTROL*	27	EVAPORATIVE EMISSION CANISTER/AIR FILTER/	EVAPORATIVE VENTILATION SOLENOID	48
GENERAL INFORMATION	6	EVAPORATIVE EMISSION CONTROL SYSTEM	37	
ON-VEHICLE SERVICE	23	Air Conditioning Switch Check	40	
Auto-cruise Control Component Check	25	Component Location	37	
Auto-cruise Control System Operation Check	25	Engine Coolant Temperature Sensor and Intake Air Temperature Sensor Check	40	
SERVICE SPECIFICATIONS	6	Evaporative Emission Purge Solenoid Check	39	
SPECIAL TOOLS	6			
TROUBLESHOOTING	7			
EMISSION CONTROL SYSTEM	29			

CONTINUED ON NEXT PAGE

WARNINGS REGARDING SERVICING OF SUPPLEMENTAL RESTRAINT SYSTEM (SRS) EQUIPPED VEHICLES

WARNING!

- Improper service or maintenance of any component of the SRS, or any SRS-related component, can lead to personal injury or death to service personnel (from inadvertent firing of the air bag), or to the driver and passenger (from rendering the SRS inoperative).
- Service or maintenance of any SRS component or SRS-related component must be performed only at an authorized MITSUBISHI dealer.
- MITSUBISHI dealer personnel must thoroughly review this manual, and especially its GROUP 32B - Supplemental Restraint System (SRS) and GROUP 00 - Maintenance Service, before beginning any service or maintenance of any component of the SRS or any SRS-related component.

NOTE

The SRS includes the following components: SRS-ECU, SRS warning light, air bag, and the clock spring and inflator assembly. Only MITSUBISHI dealer personnel should perform any work on the SRS-related components that may have to be removed, installed or replaced when SRS service or maintenance is required. For more information, contact your MITSUBISHI dealer.

General Information	37	Positive Crankcase Ventilation (PCV) Valve Check	30
Purge Control System Check	38	SERVICE SPECIFICATIONS	29
Purge Port Vacuum Check	39	SPECIAL TOOLS	29
Valve Air Flow Sensor, Engine Coolant Temperature Sensor and Intake Air Temperature Sensor Check	40	TROUBLESHOOTING	30
EXHAUST GAS RECIRCULATION (EGR) SYSTEM	41	VACUUM HOSES	31
Component Location	42	Vacuum Circuit Diagram	32
EGR Port Vacuum Check	44	Vacuum Hose Check	35
EGR Solenoid Check	44	Vacuum Hose Installation	35
EGR System Check	42	Vacuum Hose Routing	31
EGR Valve Check	43	ENGINE CONTROL SYSTEM	3
General Information	41	ACCELERATOR CABLE AND PEDAL	5
Vacuum Control Valve Check	43	GENERAL INFORMATION	3
GENERAL INFORMATION	29	ON-VEHICLE SERVICE	4
POSITIVE CRANKCASE VENTILATION SYSTEM	35	Accelerator Cable Check and Adjustment	4
Component Location	36	SERVICE SPECIFICATIONS	3
Crankcase Ventilator System Check	36	TROUBLESHOOTING	3
General Information	35		


ENGINE CONTROL SYSTEM

1710001000

GENERAL INFORMATION

The accelerator system consists of a cable and pedal. The accelerator pedal side end of the cable has a plastic bushing and damper <1.6L Engine>. They effectively suppress the noise that would result from direct contact of the cable and the accelerator arm.

CONSTRUCTION DIAGRAM



SERVICE SPECIFICATIONS

1710003000

Item	Standard value
Accelerator cable play (mm or in.)	1-2 (0.4 - 0.8)
Engine idle speed (rpm)	1.5L Engine 750 - 100
	1.6L Engine 800 - 100

TROUBLESHOOTING


1710007000

Symptom	Probable cause	Remedy
Throttle valve will not fully open or close	Misadjusted accelerator cable	Adjust
	Misadjusted auto cruise control cable	Adjust
	Broken return spring	Replace
	Throttle lever is a function	Replace
Accelerator pedal operation not smooth (lower acceleration)	Accelerator pedal wrongly tightened	Repair
	Misadjusted accelerator cable	Repair
	Accelerator cable requires lubrication	Lubricate or replace

<1.5L Engine>



<1.8L Engine>



ON-VEHICLE SERVICE

17-10000-101

ACCELERATOR CABLE CHECK AND ADJUSTMENT

- 1 Turn off the air conditioning and all lights. Inspect and adjust at no load.
- 2 Start the engine and allow to idle until it reaches normal operating temperature.
- 3 Confirm idle speed is at standard value.

Standard value:

<1.5L Engine> 750 ± 100 r/min

<1.8L Engine> 800 ± 100 r/min

- 4 Stop engine (ignition switch OFF).
- 5 Confirm there are no sharp bends in accelerator cable.
- 6 Check inner cable for correct slack.

Standard value: 1 - 2 mm (.04 - .08 in.)

- 7 If there is too much slack or no slack, adjust the cable as follows:
 - 1) Loosen the adjusting bolt to release the cable.
 - 2) Move the plate until the inner cable play is at the standard value, and then tighten the adjusting bolt to the specified torque.

- R. Adjust accelerator cable play and confirm throttle lever stopper touches the fixed BAS.





ACCELERATOR CABLE AND PEDAL

17-00000

REMOVAL AND INSTALLATION

Post-Installation Operation


- Adjusting the Accelerator Cable (Refer to E17-4)



Removal steps

1. Adjusting bolts
2. Inner cable connection (Throttle body side)
3. Inner cable connection (Accelerator pedal side)
4. Accelerator cable
5. Cutter pin
6. Accelerator pedal
7. Spring
8. Pedal pad
9. Stopper
10. Accelerator pedal stopper

AUTO-CRUISE CONTROL SYSTEM




72000-0204

GENERAL INFORMATION

By using the auto-cruise control, the driver can select and maintain a desired cruising speed

(approximately 40 km/h (25 mph) or more) without depressing the accelerator pedal.

CONSTRUCTION DIAGRAM



SERVICE SPECIFICATIONS

1720000-01

Items	Standard value
Accelerator cable play (mm (in.))	1-2 (1.04-0.26)

SPECIAL TOOLS


1720000-01

Tool	Tool number and name	Supersession	Application
	MB961502 Scan tool (MUT-II)	MB991496-0D	Diagnostic trouble code check
	MB991529 Diagnostic trouble code check harness	Not necessary if scan tool (MUT-II) is available	

TROUBLESHOOTING

17100-0038

DIAGNOSTIC TROUBLESHOOTING FLOW



NOTE

Before carrying out trouble diagnosis, check to be sure that all of the following items are normal

1. Is the vacuum hose installed correctly and is the hose not damaged?
2. Is the accelerator cable play at the standard value?



DIAGNOSTIC FUNCTION

17202-0260


METHOD OF READING THE DIAGNOSTIC TROUBLE CODES

Using the scan tool

Caution

To prevent damaged to the scan tool, make sure the ignition switch is "OFF" before connecting or disconnecting the scan tool.

1. Turn the ignition switch "OFF."
2. Connect the scan tool to the data link connector.
3. Use the scan tool to check for auto-cruise control system diagnostic trouble codes.
4. Turn the ignition switch "OFF."
5. Disconnect the scan tool.




Using a auto-cruise control indicator light

1. Push the main switch to 'ON.'
2. With the "SET" switch at the "ON" position turn the ignition switch "ON," and within one second after this, turn the "RESUME" switch to "ON."
3. Take a reading of a diagnostic trouble code based on the flashing of the auto-cruise control indicator light in the combination meter.

DIAGNOSTIC RESULT DISPLAY METHOD WHEN USING THE AUTO-CRUISE CONTROL INDICATOR LIGHT


When the diagnostic trouble code No.20 is output



When no diagnostic trouble code is output



NOTE
Other diagnosis items are also output as voltage waveforms corresponding to diagnosis code numbers



METHOD OF ERASING DIAGNOSTIC TROUBLE CODES

Erase the diagnostic trouble codes with the following procedure.

NOTE

The diagnostic trouble codes will not be erased even if the battery (-) terminal is disconnected.

Using the scan tool


Caution

To prevent damage to the scan tool, make sure the ignition switch is "OFF" before connecting or disconnecting the scan tool.

- 1 Turn the ignition switch "OFF."
- 2 Connect scan tool to the data link connector.
- 3 Use scan tool to check for auto-cruise control system diagnostic trouble codes.
- 4 Turn the ignition switch "OFF."
- 5 Disconnect the scan tool.

Without using the scan tool

- 1 Turn the ignition switch "ON."
- 2 Push the auto-cruise control switch in the direction of arrow (B) in the illustration, and within one second after doing this, push the auto-cruise control switch back in the direction of arrow (A).
- 3 Push the auto-cruise control switch again in the direction of arrow (B) in the illustration. While holding the switch in this position, press the stop light switch to the "ON" position for five seconds or more.



INPUT SWITCH CODE CHECK METHOD

- 1 Connect the scan tool to the data link connector (18-pin) under the instrument panel under cover.
- 2 Turn the ignition switch to ON.
- 3 After pushing the auto-cruise control switch in the direction of arrow (B) in the illustration, press the cruise control main switch to the ON position, and within 1 second after doing this, push the cruise control switch back in the direction of arrow (A).
- 4 Operate each switch listed in the input check table and take a reading of the input switch codes with the scan tool.

17-10 ENGINE AND EMISSION CONTROL - Auto-cruise Control System**Input Inspection Table**

17-10-10

Code No.	Input operation	Operation judgement
21	SET switch ON	Auto-cruise control-ECU judges that SET switch is ON
22	RESUME switch ON	Auto-cruise control-ECU judges that RESUME switch is ON
23	Stop light switch (ON when brake pedal depressed)	Auto-cruise control-ECU judges that stop light switch is ON
24	Vehicle speed signal	Auto-cruise control-ECU judges that vehicle speed is 40 km/h (25 mph) or higher
25		Auto-cruise control-ECU judges that vehicle speed is lower than 40 km/h (25 mph)
26	<ul style="list-style-type: none"> ● Clutch pedal position switch <MT> (ON when clutch pedal depressed) ■ Park/neutral position switch <AT> (ON when select lever in N range) 	Auto-cruise control-ECU judges that clutch pedal position switch <MT> or park/neutral position switch <AT> is ON
27	CANCEL switch ON	Auto-cruise control-ECU judges that CANCEL switch is ON
28	Throttle position sensor signal	Auto-cruise control-ECU judges that throttle position sensor voltage is 1.5 V or more
29	Closed throttle position switch	Auto-cruise control-ECU judges that closed throttle position switch is OFF

INSPECTION CHART FOR DIAGNOSTIC TROUBLE CODES

17-10-11

Code No.	On-board diagnostic items	Reference page
11	Auto-cruise vacuum pump drive system	17-11
12	Vehicle speed sensor system	17-11
14	Auto-cruise vacuum pump power supply system	17-12
15	Auto-cruise control switch	17-12
16	Auto-cruise control-ECU	17-12
17	Throttle position sensor system	17-13

INSPECTION PROCEDURE FOR DIAGNOSTIC TROUBLE CODES

Code No. 11 Auto-cruise vacuum pump drive system

This diagnostic trouble code is output if the vehicle speed control system malfunctions. Check signal from the auto-cruise vacuum pump drive system to the auto-cruise control ECU.

Probable cause

- Malfunction of the auto-cruise vacuum pump
- Malfunction of the hose/pipe
- Malfunction of the harness
- Malfunction of the auto-cruise control ECU

Check the auto-cruise vacuum pump.
(Refer to P.17-25)

NG

→ Repair

OK

Check the following connector:
4-37, B-25

NG

→ Repair

OK

Check trouble symptoms

NG

→ There is no hose between the auto-cruise vacuum pump and auto-cruise control ECU.

OK

→ Replace the auto-cruise control ECU.

NG

Repair

Code No. 12 Vehicle speed signal system

This diagnostic trouble code is output if the vehicle speed signal from the vehicle speed sensor and its signal to the auto-cruise control ECU when the vehicle speed is 40 km/h or more.

Probable cause

- Malfunction of the vehicle speed sensor
- Malfunction of the connector
- Malfunction of the harness
- Malfunction of the auto-cruise control ECU

Is the speedometer operation normal?

NG

→ vehicle speed sensor circuit inspection (refer to P.17-24 - 25) or consult a mechanic.

Yes

Disconnect the vehicle speed sensor connector A-27.

OK

→ Check the following connector: B-25

→ Repair

OK

Measure at auto-cruise control ECU connector B-25.

- Disconnect the connector and measure at the harness side.
- Voltage between terminal (1) and (2): no
DK: 4.5 V or more

OK

→ Check the following connector: B-25

→ Repair

OK

Check trouble symptoms

OK

Inspect the auto-cruise control ECU.

NG

Check the harness between the vehicle speed sensor and auto-cruise control ECU, and repair if necessary.

Code No. 14 Auto-cruise vacuum pump power supply system	Probable cause
<p>The diagnostic trouble code is output when one of the diagnostic signals (engine speed, throttle valve and motor) of the auto-cruise vacuum pump are open to the auto-cruise control ECU.</p>	<ul style="list-style-type: none"> Malfunction of the stop light switch Malfunction of the connector Malfunction of the harness Malfunction of the auto-cruise control ECU Malfunction of the auto-cruise vacuum pump

<p>Measure of auto-cruise vacuum pump connector A-07</p> <ul style="list-style-type: none"> Disconnect the connector and measure at the harness side. Voltage between terminal 11 and ground <p>OK: System voltage</p> <p>NG</p> <p>Check the stop light switch. Refer to P17-221.</p> <p>OK</p> <p>NG</p> <p>Replace</p> <p>Check the following connectors: A-27, B-03, d-03, b-25</p> <p>OK</p> <p>Check trouble symptom</p> <p>NG</p> <p>Check the harness between the auto-cruise vacuum pump and auto-cruise control ECU.</p> <p>OK</p> <p>NG</p> <p>Repair</p> <p>Replace the auto-cruise control ECU.</p>	<p>Check the auto-cruise vacuum pump (Refer to P17-21)</p> <p>OK</p> <p>NG</p> <p>Replace</p> <p>Measure of auto-cruise control ECU connector B-26</p> <ul style="list-style-type: none"> Disconnect the connector and measure at the harness side. Voltage between terminal 11 and ground for stop light switch Voltage between terminal 11 and ground for engine speed sensor Voltage between terminal 15 and ground for throttle valve <p>OK: System voltage</p> <p>OK</p> <p>NG</p> <p>Check the following connector B-26</p> <p>OK</p> <p>Check trouble symptom</p> <p>NG</p> <p>Replace the auto-cruise control ECU.</p>	<p>Replace</p> <p>Check the following connectors: A-27, d-03</p> <p>OK</p> <p>NG</p> <p>Repair</p> <p>Check trouble symptom</p> <p>OK</p> <p>NG</p> <p>Repair</p> <p>Check the harness between the auto-cruise vacuum pump and auto-cruise control ECU and repair if necessary.</p>
---	--	---

Code No. 15 Auto-cruise control switch	Probable cause
<p>The diagnostic trouble code is output if there is an abnormality in the CANCEL switch or the CANCEL switch remains ON.</p>	<ul style="list-style-type: none"> Malfunction of the auto-cruise control switch

Replace the auto-cruise control switch.

Code No. 16 Auto-cruise control ECU	Probable cause
<p>The diagnostic trouble code is output if there is an abnormality in the CANCEL node circuit of the auto-cruise control ECU.</p>	<ul style="list-style-type: none"> Malfunction of the auto-cruise control ECU

Replace the auto-cruise control ECU.

Code No.17 Throttle position sensor system

Probable cause

This diagnostic trouble code is output if a voltage of 1.5 V or more when the driver checks present switch. Only at 0.2 V or less when the driver checks position switch is 011. It is output for a continuous period of 4 seconds or more.

- ▶ Malfunction of the throttle position sensor
- ▶ Malfunction of the connector
- ▶ Malfunction of the harness
- ▶ Malfunction of the auto-cruise control ECU

Scan tool diagnostic trouble code is displayed. Is the code No. 17 output from the engine control module?

Yes

- ▶ Inspect throttle position sensor (check if the terminal GROUND is not disconnected).

NO

Check the following connectors: ECU, IP-08

NG

- ▶ Repair

OK

Check throttle operation

NG

- ▶ Inspect the clearance between the throttle position sensor and auto-cruise control ECU

NG

- ▶ Repair

OK

Replace the auto-cruise control ECU

INSPECTION CHART FOR TROUBLE SYMPTOMS


1700000017

Trouble symptom		Inspection procedure No.	Reference page
Communication with scan tool is not possible	Communication with all systems is not possible.	1	17-13
	Communication with auto-cruise control ECU only is not possible	2	17-14
Input switch inspection using the scan tool is not possible (However, diagnosis inspection is possible)		3	17-15
Auto-cruise control is not cancelled.	Even if brake pedal is depressed	4	17-16
	Even if clutch pedal is depressed (MT)	5	17-17
	Even if select lever is set to N range (AT)	6	17-17
	Even if CANCEL switch is set to ON	7	17-19
Auto-cruise control cannot be set.		9	17-19
Flucting (repeated acceleration and deceleration) occurs at the set vehicle speed.		10	17-19
Auto-cruise control indicator light inside combination meter does not illuminate. (However, auto-cruise control is normal)		11	17-21

INSPECTION PROCEDURE FOR TROUBLE SYMPTOMS

INSPECTION PROCEDURE 1

Communication with scan tool is not possible. (Communication with all systems, is not possible.)	Probable cause
The reason is probably a defect in the power supply system (including grounds) for the diagnosis. (→	<ul style="list-style-type: none"> • Malfunction of the fusebox • Malfunction of the battery



INSPECTION PROCEDURE 2


2/1

Communication with scan tool is not possible (Communication with auto-cruise control-ECU only is not possible.)

The reason is probably a malfunction of the auto-cruise control switch, a fault of a malfunction of the auto-cruise control-ECU or a fault of a

Probable cause

- Malfunction of the auto-cruise control switch
- Malfunction of the connector
- Malfunction of the harness
- Malfunction of the auto-cruise control-ECU



INSPECTION PROCEDURE 3

Input switch inspection using the scan tool is not possible.
(However, diagnosis inspection is possible.)

The cause is probably a malfunction of auto-cruise control power supply system.

Probable cause

- Malfunction of the auto-cruise control switch
- Malfunction of the check string
- Malfunction of the connector
- Maloperation of the harness

Auto-cruise control (check Refer to P.17-26)

OK

- Check spring frame (Refer to GFC,UP,UP No. Eng. Manual and Check String)

OK

Minimum of check string connector C-11

- Measure
- Voltage between terminal 21 and ground
OK: system voltage

OK

Check the following connectors: C-10, C-11 and P-20

OK

Check trouble symptom

NG

→ Replace

NG

→ Replace

NG

→ Check the following connectors: B-67, B-67 B-66 and C-11

NG

→ Repair

OK

Check trouble symptom

NG

→ Check the harness between the check string and power supply and repair if necessary

NG

→ Repair

NG

→ Check the harness between the check string and G.L. (check terminal-C11) and repair if necessary

INSPECTION PROCEDURE 4

Even if brake pedal is depressed, auto-cruise control is not cancelled.

The cause is probably a malfunction of stop light switch or a malfunction of stop light bulb.

Probable cause

- Malfunction of the stop light switch
- Malfunction of the connector
- Malfunction of the fuse box
- Malfunction of the auto-cruise control ECU

Does stop light illuminate?

No

Stop light switch check
(Refer to P17-26)

OK

NG

Repair

Yes

➤ Check the following connector.
R25

OK

➤ Check trouble symptoms

NG

➤ Check the harness between the stop light switch and auto-cruise control ECU

OK

➤ Repair the auto-cruise control ECU

Yes

➤ Repair

Measure in stop light switch connector
40C

- Disconnect the connector and measure at the harness side
 - Voltage between terminal 21 and ground
- OK: Ignition voltage

OK

Check the following connectors.
B106, 425

OK

➤ Check trouble symptoms

NG

➤ Check the following connector.
B11

OK

➤ Check trouble symptoms

Yes

➤ Repair

NG

➤ Check the harness between the stop light switch and stop light supply and/or if necessary

NG

➤ Repair

NG

➤ Check the harness between the stop light switch and auto-cruise control ECU and repair if necessary


INSPECTION PROCEDURE 5

Even if clutch pedal position switch is depressed, auto-cruise control is not cancelled. <M/T>

Probable cause

The cause is probably a malfunction of clutch pedal position switch or clutch circuit.

- Malfunction of the clutch pedal position switch
- Malfunction of the connector
- Malfunction of the harness
- Malfunction of the auto-cruise control ECU




INSPECTION PROCEDURE 6

Even if select lever is set to N range, auto-cruise control is not cancelled. <A/T>

Probable cause

The cause is probably an open circuit in the neutral signal circuit in N range.

- Malfunction of the park neutral position switch
- Malfunction of the connector
- Malfunction of the harness
- Malfunction of the auto-cruise control ECU



INSPECTION PROCEDURE 7

Even if auto-cruise control CANCEL switch is set to ON, auto-cruise control is not cancelled.

Probable cause

The cause is probably an operational malfunction of the cancel switch (CANCEL switch).

- Malfunction of the auto-cruise control sensor

Replace the auto-cruise control sensor.

INSPECTION PROCEDURE 9

Auto-cruise control cannot be set.

Probable cause

The cause is probably that the fail-safe function is cancelling auto-cruise control. In this case, the scan tool can be used to turn the fail-safe system, in each system, by erasing the diagnostic trouble codes. The scan tool can also be used to check if the status of the cancel switch and manual cancel by inspecting the main switch codes.

- Malfunction of the auto-cruise control sensor
- Malfunction of the clock system
- Malfunction of the transmission oil pressure sensor
- Malfunction of the shift/park/neutral position switch (N/P/S)
- Malfunction of the park/neutral position switch (P/N)
- Malfunction of the auto-cruise control-ECU

Can the auto-cruise control communicate with the scan tool?

No

- Inspection for wiring fault in the system (Refer to inspection procedure No. 2 on P.17-15.)

Yes

Are any of scan tool diagnostic trouble code Nos. 11, 12, 13, 14, 15, 16 or 17 set?

Yes

- Inspection for each diagnostic trouble code.
 (Code No. 11 Refer to P.17-14.)
 (Code No. 12 Refer to P.17-11.)
 (Code No. 13 Refer to P.17-12.)
 (Code No. 14 Refer to P.17-12.)
 (Code No. 15 Refer to P.17-12.)
 (Code No. 16 Refer to P.17-12.)
 (Code No. 17 Refer to P.17-12.)

Yes

Is input switch inspection possible with the scan tool?

No

- Inspection for wiring fault in the system (Refer to inspection procedure No. 1 on P.17-15.)

Yes

Are either of scan tool input switch code Nos. 27 or 28 output?

Yes

- Check the switch operation of system (code No. 27) or N/P/S (Refer to inspection procedure No. 12 on P.17-20.)
- Check park/neutral position switch (N/P) or park/neutral/position switch (P/N/S) input circuit system (code No. 28) or P/N/S (Refer to inspection procedure No. 13 on P.17-21.)

Yes

Replace the auto-cruise control ECU.

INSPECTION PROCEDURE 10

Hunting (repeated acceleration and deceleration) occurs at the set vehicle speed.

Probable cause

The cause is probably a malfunction of vehicle speed sensor or motor valve with in the motor check valve or solenoid.

- Malfunction of the vehicle speed sensor
- Malfunction of the solenoid or vacuum pump
- Malfunction of the indicator
- Malfunction of the auto-cruise control ECU

Vehicle speed sensor check (Refer to CIRCUIT 24 - Continental Motor) NG → Replace

OK

A.C. motor - vacuum pump check (Refer to P.17-20) NG → Replace

OK

Vacuum indicator check (Refer to P.17-20) NG → Replace

OK

Replace the auto-cruise control ECU

INSPECTION PROCEDURE 11

Auto-cruise control indicator lamp inside combination meter does not illuminate. (However, auto-cruise control is normal.)

Probable cause

The cause is probably a malfunction of the valve or a malfunction of the connector or harness.

- Malfunction of the valve
- Malfunction of the harness
- Malfunction of the connector
- Malfunction of the auto-cruise control ECU

Combination meter check NG → Replace

OK

Measure at auto-cruise control ECU connector (C24) NG → Check the following connector NG → Repair

- Disconnect the connector and measure at P.E. harness side
 - Voltage between terminals (15) and ground
- OK. System voltage

OK

Check trouble symptom

NG

Replace the auto-cruise control ECU

Check the harness between the connector between meter and auto-cruise control ECU and repair if necessary

INSPECTION PROCEDURE 12

Stop light switch input circuit system inspection (Code No. 23)

Check the following connectors: B-27 B-16 B-26 NG → Repair

OK

Check harness system NG → Check the harness between Launch 14-14-2 and auto-cruise control ECU and repair if necessary

INSPECTION PROCEDURE 13

Clutch pedal position switch <M.T.> or park/neutral position switch <A.T.> input circuit system inspection (Code No. 26)

<M.T.>

<A.T.>

Clutch pedal position switch check (Refer to P17-26)

Check the following connectors
 (1) 26 (1) 27 (1) 28

Check trouble symptom

OK

→ Replace

Check the terminals between auto-cruise control ECU and power supply


NG

→ Replace

NG

→ Check the terminals between auto-cruise control ECU and ground and repair if necessary


CHECK AT THE ECU TERMINALS



0710050

Terminal No.	Check item	Check conditions	Normal condition
1	Throttle position sensor input	When accelerator pedal is fully depressed	4.5 - 0.5V
		When accelerator pedal is released	0.3 - 1.0V
2	Closed throttle position switch output	When accelerator pedal is depressed	When closed throttle position switch is OFF
		When accelerator pedal is not depressed	When closed throttle position switch is ON
3	A/T oiling output	No OD-OFF request	System voltage
		OD-OFF request	0V
4	Stop light switch input	When brake pedal is depressed	When stop light switch is "ON"
		When brake pedal is not depressed	When stop light switch is "OFF"
5	Pump power supply	Ignition switch: ON Stop light switch: OFF	System voltage
6	ECU power supply	Ignition switch: ON	System voltage
7	Auto cruise vacuum pump release valve and control valve input	When accelerating with the SET switch while driving at constant speed	Control valve open
When canceling constant speed driving with the CANCEL switch		Release valve open	
When canceling constant speed driving with the CANCEL switch		Control valve open	
8	Auto cruise control switch input	When main switch ON	System voltage
When input switch has not been operated		When all switches are OFF	
When input switch is pushed down		When SET switch is ON	
When input switch is pushed up		When RESUME switch is ON	
9	Vehicle speed sensor input	When vehicle is moved forwards and backwards, sensor turns ON and OFF repeatedly	When sensor is ON
			When sensor is OFF
11	Diagnosis control input	When ignition switch is ON	4V or more

Terminal No.	Check item	Check conditions	Normal condition
12	ACG power supply	When ignition switch is in ACG position Main switch ON	System voltage
13	Clutch pedal position switch input (M/T)	When pedal is not depressed	When clutch pedal position switch is OFF
		When pedal is depressed	When clutch pedal position switch is ON
	Park/neutral position switch input (A/T)	When select lever is in a position other than N range	When park/neutral position switch is OFF
		When select lever is in N range	When park/neutral position switch is ON
14	Ground	At any time	Continuity
15	Indicator input inside combination meter	When driving at constant speed	When indicator is illuminated
		When constant-speed driving is cancelled	When indicator is switched off
16	Auto-cruise vacuum pump motor input	When driving at constant speed using the SET ⁺ switch	Motor stopped/humming
		When accelerating with the RESUME switch while driving at constant speed	Motor stopped/humming
		When decelerating with the SET ⁻ switch while driving at constant speed	Motor stopped
		When cancelling constant speed driving with the CANCEL switch	Motor stopped



ON-VEHICLE SERVICE

172000010

AUTO-CRUISE CONTROL SYSTEM OPERATION CHECK

AUTO-CRUISE CONTROL SWITCH INDICATOR LIGHT

- 1 Turn the ignition switch to "ON"
- 2 Check that the indicator light within the combination meter illuminates when the main switch is turned to "ON"

AUTO-CRUISE CONTROL SETTING

1. Switch ON the main switch.
2. Drive at the desired speed above approximately 40 km/h (25 mph).
3. Push the auto-cruise control switch in the direction of arrow (E).
4. Check to be sure that when the switch is released the speed is the desired constant speed.

NOTE

If the vehicle's speed decreases to approximately 15 km/h (9 mph) below the set speed because of climbing a hill for example, the auto-cruise control will be cancelled.

SPEED-INCREASE SETTING

1. Set to the desired speed.
2. Push the auto-cruise control switch in the direction of arrow (A).
3. Check to be sure that acceleration continues while the switch is held, and that when it is released the constant speed at the time when it was released becomes the driving speed.

NOTE

Acceleration can be continued even if the vehicle speed has passed the high speed limit (approximately 203 km/h (124 mph)). But the speed when the auto-cruise control switch is released will be recorded as the high-speed limit.

SPEED-REDUCTION SETTING





1. Set to the desired speed.
2. Push the auto-cruise control switch in the direction of arrow (B).
3. Check to be sure that deceleration continues while the switch is pressed, and that when it is released the constant speed at the time when it was released becomes the driving speed.

NOTE

When the vehicle speed reaches the low limit (approximately 40 km/h (25 mph)) during deceleration, the auto-cruise control will be cancelled.

RETURN TO THE SET SPEED BEFORE CANCELLATION AND AUTO-CRUISE CONTROL CANCELLATION

1. Set the auto-cruise speed control.
2. When any of the following operations are performed while at constant speed during auto-cruise control, check if normal driving is resumed and deceleration occurs.
 - a. The auto-cruise control switch is pushed in the direction of arrow (C).
 - b. The brake pedal is depressed.
 - c. The clutch pedal is depressed. (M.T)
 - d. The selector lever is moved to the 'N' range. (A/T)



- At a vehicle speed of 40 km/h (25 mph) or higher, check if when the RESUME switch is switched ON, vehicle speed returns to the speed before auto-cruise control driving was cancelled, and constant speed driving occurs.
- When the main switch is turned to OFF while driving at constant speed, check if normal driving is resumed and deceleration occurs.

AUTO-CRUISE CONTROL COMPONENT CHECK

172001 A4.UM

STOP LIGHT SWITCH

Refer to GROUP 35A - On-vehicle Service

CLUTCH PEDAL POSITION SWITCH (M/T)


Refer to GROUP 21 - On-vehicle Service

PARK/NEUTRAL POSITION SWITCH ("N" POSITION)

Refer to GROUP 33A - On-vehicle Service

THROTTLE POSITION SENSOR


Refer to GROUP 13A - On-vehicle Service



AUTO-CRUISE VACUUM PUMP

- Disconnect the vacuum hose from the auto-cruise vacuum pump and connect a vacuum gauge to the vacuum pump.
- Disconnect the vacuum pump connector.
- Check that the reading on the vacuum gauge matches the values in the table below when the battery is connected to each connector terminal.

Terminal No.	Valve condition	Vacuum gauge kPa (mm Hg, in. Hg)
1 2 3 4	Release valve closed Control valve closed	55 (398, 15.7) or more
1 2 3 4	Release valves open Control valve open	20 (150, 5.9) or less



**VACUUM ACTUATOR**


- 1 Disconnect the vacuum hose from the vacuum actuator, and connect a hand vacuum pump to the actuator.
- 2 Check that the throttle lever operates when applying vacuum, and the vacuum is kept.

AUTO-CRUISE CONTROL CHECK

Measure the resistance between the terminals when each of the "SET," "RESUME," "CANCEL" and "MAIN" switches is pressed. If the values measured at the time correspond to those in the table below then there is no problem.



931-0108


 030106
 00004225

Switch position	Resistance between terminals	
Switch "OFF"	No continuity	
"CANCEL" switch "ON"	Terminals 1 and 3	Approximately 3.3 k Ω
	Terminals 2 and 3	Approximately 0 Ω
"RESUME" switch "ON"	Terminals 1 and 3	Approximately 4.5 k Ω
	Terminals 2 and 3	Approximately 910 Ω
"SET" switch "ON"	Terminals 1 and 3	Approximately 4.1 k Ω
	Terminals 2 and 3	Approximately 220 Ω
"MAIN" switch "ON"	Terminals 1 and 2	Approximately 0.6 k Ω


VEHICLE SPEED SENSOR CHECK

Refer to GROUP 54 - Combination meters.

AUTO-CRUISE CONTROL

170001-10076

REMOVAL AND INSTALLATION

**Auto-cruise vacuum pump removal steps**


1. Vacuum hose
2. Bracket
3. Auto-cruise vacuum pump end bracket assembly
4. Auto-cruise vacuum pump assembly
5. Pump bracket

CAUTION, SRS

Before removal of the air bag module, refer to the following groups.

GROUP 52B - SRS Service Precautions.

GROUP 52B - Air Bag Modules and Clock Spring.


Control unit removal

6. Auto-cruise control-ECU:
Control switch removal

Control switch removal

- Air bag module (Refer to GROUP 52B.)
- 7. Control switch

Sensor removal

- 8. Throttle position sensor
- 9. Park neutral position switch (A/T.)
- 10. Stop light switch
- 11. Clutch pedal position switch (M.T.)

EMISSION CONTROL SYSTEM

17-00010177

GENERAL INFORMATION

The emission control system consists of the following subsystems:

- Positive crankcase ventilation system
- Evaporative emission control system
- Exhaust emission control system



SERVICE SPECIFICATIONS

17-00000114

Item	Specification
Evaporative emission purge solenoid coil resistance (at 20 °C (66 °F)) :	35-44
ECM solenoid coil resistance (at 20 °C (66 °F)) :	35-44

SPECIAL TOOLS

17-00000110

Tool	Tool number and name	Supersession	Application
	ML93B773 Oxygen sensor wrench	ML93B770 (1) or general service tool	Removal / installation of heated oxygen sensor
	MO995361 Purge flow indicator		Inspection of purge control system

TROUBLESHOOTING

17-037-2013


Symptom	Probable cause	Remedy
Engine will not start or hard to start.	Vacuum hose disconnected or damaged	Repair or replace
	The EGR valve is not closed	Repair or replace
	Malfunition of the evaporative emission purge solenoid	Repair or replace
Rough idle or engine stalls	The EGR valve is not closed	Repair or replace
	Vacuum hose disconnected or damaged.	Repair or replace
	Malfunition of the positive crankcase ventilation valve	Replace
	Malfunition of the purge control system	Check the system; if there is a problem, check its component parts.
Engine hesitates or poor acceleration	Malfunition of the exhaust gas recirculation system	Check the system; if there is a problem, check its component parts.
Excessive oil consumption	Positive crankcase ventilation line clogged	Check positive crankcase ventilation system
Poor fuel mileage	Malfunition of the exhaust gas recirculation system	Check the system; if there is a problem, check its component parts

VACUUM HOSES

1136000000


VACUUM HOSE ROUTING

<1.5L Engines>



17M0431

<1.8L Engine>




- L Light Blue
- B Black
- G Green
- Y Yellow
- W White
- * Not red-print mark

Right

SI-MC-267

VACUUM CIRCUIT DIAGRAM


<1.6L Engine>



F Light Blue
 R Red
 B Black
 G Green
 Y Yellow
 W White

* With red seal mark

<1.8L Engine>



VACUUM HOSE INSTALLATION

1. When connecting the vacuum hoses they should be securely inserted onto the nipples.
2. Connect the hoses correctly. Using the VACUUM HOSE ROUTING as a guide.

VACUUM HOSE CHECK

1. Using the VACUUM HOSE ROUTING as a guide check that the vacuum hoses are correctly connected.
2. Check the connection of the vacuum hoses. (removed, loose, etc.) and check that there are no bends or damage.


POSITIVE CRANKCASE VENTILATION SYSTEM

17-356402-1/1



GENERAL INFORMATION

The positive crankcase ventilation system is a system for preventing the escape of blow-by gases from inside the crankcase into the atmosphere. Fresh air is sent from the cleaner into the crankcase through the breather hose to be mixed with the blow-by gas inside the crankcase. The blow-by gas inside the crankcase is drawn into the intake manifold through the positive crankcase ventilation (PCV) valve.

The PCV valve is designed to lift the plunger according to the intake manifold vacuum so as to regulate the flow of blow-by gas properly. In other words, the blow-by gas flow is regulated during low load engine operation to maintain engine stability, while the flow is increased during high load operation to improve the ventilation performance.

SYSTEM DIAGRAM

COMPONENT LOCATION



CRANKCASE VENTILATION SYSTEM CHECK


112001046

- (1) Remove the positive crankcase ventilator (PCV) valve from the rocker cover, then reconnect the PCV valve to the vacuum supply hose.
- (2) With the engine idling, put finger on the open end of the PCV valve, and check for negative pressure (vacuum) with finger.

NOTE

At this time, the plunger in the PCV valve should move back and forth as the open end is covered and uncovered.

- (3) If negative pressure is not felt, clean or replace the PCV valve. Inspect the vacuum supply hose and its port for restriction or plugged condition.



POSITIVE CRANKCASE VENTILATION (PCV) VALVE CHECK

112001046

- (1) Hold the PCV valve with the vacuum side down. Using light pressure, depress the PCV valve spring with the 1/16 in. stick 5 - 10 mm (20 - 39 in.). Release pressure on the stick to see if the PCV valve spring will lift the stick to its original position.
- (2) If the stick returns quickly to its original position, the PCV valve is OK. If the stick does not return quickly, clean or replace the PCV valve.

EVAPORATIVE EMISSION CONTROL SYSTEM

GENERAL INFORMATION

The evaporative control system prevents fuel vapors generated in the fuel tank from escaping into the atmosphere.

Fuel vapors from the fuel tank flow through the fuel tank pressure control valve and vapor pipe/hose to be stored temporarily in the EVAP canister.

When the vehicle is in operation, fuel vapors stored in the EVAP canister flow through the EVAP purge solenoid and purge port and go into the intake manifold plenum to be sent to the combustion chamber.


When the engine coolant temperature is low or when the intake air quantity is small (when the engine is at idle, for example), the engine control module brings the EVAP purge solenoid into the

OFF state to shut off the fuel vapor flow to the intake manifold plenum. This does not only ensure the driveability when the engine is cold or running under low load but also stabilize the emission level. In addition, the EVAP vent solenoid is provided between the EVAP canister and atmospheric air to carry out OBD-II EVAP leak monitor.

This solenoid valve is a way-off, but if OBD-II EVAP leak monitor is being carried out, the valve will be turned on to prevent atmospheric air from entering the EVAP canister.

Moreover, the fuel vent valve is provided to the fuel filler tube to prevent excessive fuel from entering the fuel tank.


SYSTEM DIAGRAM



LE004-04

COMPONENT LOCATION

Evaporative emission purge solenoid
(1.5L Engines)



Evaporative emission purge solenoid
(1.8L Engines)



JE02704

Purge port vacuum nipple



17-00127

Purge vacuum nipple



97-02737

PURGE PORT VACUUM CHECK

17-00126/263

<1.5L Engine>

1. Disconnect the vacuum hose (red stripe) from the throttle body purge vacuum nipple and connect a hand vacuum pump to the nipple.

<1.8L Engine>

Disconnect the vacuum hose (black) from the intake air plenum vacuum nipple and connect a hand vacuum pump to the nipple.

2. Start the engine and check to see that, after raising the engine speed by racing the engine, purge vacuum is kept constant regardless of the increased engine speed.

NOTE

If there is no vacuum created, it is possible that the intake air plenum cone may be clogged and require cleaning.



97-02737


EVAPORATIVE EMISSION PURGE SOLENOID CHECK

17-00127/263

NOTE


When disconnecting the vacuum hose, always make a mark so that it can be reconnected at its original position.

1. Disconnect the vacuum hose (black, red stripe) from the solenoid valve.
2. Disconnect the harness connector.
3. Connect a hand vacuum pump to nipple to nipple (A) of the solenoid valve (refer to the illustration at left).
4. Check airtightness by applying a vacuum with voltage applied directly from the battery to the purge control solenoid valve and without applying voltage.



17-00127

Factory voltage	Normal condition
Applied	Vacuum leaks
Not applied	Vacuum maintained



5. Measure the resistance between the terminals of the solenoid valve.

Standard value: 38 - 44 Ω (at 20 C (68 F))

ENGINE COOLANT TEMPERATURE SENSOR AND INTAKE AIR TEMPERATURE SENSOR CHECK <1.5L Engine>

17200180200

To check these parts, refer to GROUP 13A - On-vehicle Service.

VOLUME AIR FLOW SENSOR, ENGINE COOLANT TEMPERATURE SENSOR AND INTAKE AIR TEMPERATURE SENSOR CHECK <1.8L Engine>

17200180200

To inspect these parts, refer to GROUP 13A - On-vehicle Service.

AIR CONDITIONING SWITCH CHECK

1720000000

To inspect the conditioning switch, refer to GROUP 50 - Air Conditioning Switch.

EXHAUST GAS RECIRCULATION (EGR) SYSTEM

172669764.00

GENERAL INFORMATION

The exhaust gas recirculation (EGR) system lowers the nitrogen oxide (NOx) emission level. When the air/fuel mixture combustion temperature is high, a large quantity of nitrogen oxides (NOx) is generated in the combustion chamber. Therefore, this system recirculates part of emission gas from

the exhaust part of the cylinder head to the combustion chamber through the intake manifold to decrease the air/fuel mixture combustion temperature resulting in reduction of NOx. The EGR flow rate is controlled by the EGR valve so as not to decrease the driveability.

OPERATION


When the engine coolant temperature is low, when the engine is at idle or when a wide open throttle operation is performed, the EGR valve is kept closed, achieving no EGR.

After warming up of the engine, EGR valve is opened.

The engine control module monitors the EGR system and illuminates the check engine-malfunction

indicator lamp to indicate that there is a malfunction.


SYSTEM DIAGRAM



11CM035C

COMPONENT LOCATION

EGR solenoid
 •1.5L Engine>



EGR valve
 •1.5L Engine>



EGR solenoid
 •1.8L Engine>



EGR valve
 •1.8L Engine>



EGR SYSTEM CHECK


17-00000010

1. Disconnect the vacuum hose (green stripe) from the EGR valve, and then connect a hand vacuum pump via the three-way terminal.
2. Regarding the engine in cold and hot conditions, check the position of vacuum when engine rpm is increased by opening the throttle valve quickly.

When engine is cold

[Engine coolant temperature: 20 C (68 F) or less]

Throttle cable	Normal vacuum condition
Open quickly	No vacuum will generate (remained as barometric pressure)

**When engine is hot**

[Engine coolant temperature: 80 C (176 F) or less]

Throttle valve	Normal vacuum condition
Open quickly	It will momentarily rise over 12kPa (2.9 in. Hg)

3. Disconnect the three-way terminal.
4. Connect the hand vacuum pump directly to the EGR valve.
5. Check whether the engine stalls or the idling is unstable when a vacuum of 20kPa (6.7 in Hg) or higher is applied during idling.

**VACUUM CONTROL VALVE CHECK**

1730276020


1. Disconnect the vacuum hose (white stripe) from the vacuum control valve and connect the hand vacuum pump to the vacuum control valve.
2. Plug the end of the removed vacuum hose.
3. Start the engine and run at idle.
4. Check the vacuum condition.

Engine condition	Normal vacuum condition
Idling	Approx. 23kPa (6.7 in Hg)

EGR VALVE CHECK

1730226070

1. Remove the EGR valve and inspect for sticking, carbon deposits, etc. If found, clean with a suitable solvent so that the valve seats correctly.



2. Connect a hand vacuum pump to the EGR valve.
3. Apply 10kPa (30 in Hg) of vacuum, and check to be sure that the vacuum is maintained.
4. Apply a vacuum and check the passage of air by blowing through one side of the EGR passage.

Vacuum	Passage of air
5.0kPa (1.6 in Hg) or less	Air is not blown out
20kPa (6.7 in Hg) or more	Air is blown out



- Reinstall the EGR valve, using a new gasket, and tighten to the specified torque.

Tightening torque: 22 Nm (16 ft lbs.)


EGR PORT VACUUM CHECK

17-0000020

- Disconnect the vacuum hose (green stripe) from the throttle body EGR vacuum nipple and connect a hand vacuum pump to the nipple.



- Start the engine and check to see that, after rapidly increasing engine rpm, vacuum remains fairly constant.



EGR SOLENOID CHECK

17-0000020

NOTE


When disconnecting the vacuum hose, always make so that it can be reconnected at original position.

- Disconnect the vacuum hose (yellow stripe, white stripe) from the solenoid valve.
- Disconnect the harness connector.



3. Connect a hand vacuum pump to the nipple in which the white-striped vacuum hose was connected
4. Check airtightness by applying a vacuum with voltage applied directly from the battery to the EGR control solenoid valve and without applying voltage

Battery voltage	Normal condition
Not applied	Vacuum leaks
Applied	Vacuum maintained



5. Measure the resistance between the terminals of the solenoid valve

Standard value: 36 - 44 Ω [at 20°C (68°F)]

CATALYTIC CONVERTER


GENERAL INFORMATION

The three-way catalytic converter, together with the closed loop air-fuel ratio control based on the oxygen sensor signal, oxidizes carbon monoxides (CO) and hydrocarbons (HC) and reduces nitrogen oxides (NOx).


When the mixture is controlled at stoichiometric air-fuel ratio, the three-way catalytic converter provides the highest purification against the three constituents, namely, CO, HC and NOx.

REMOVAL AND INSTALLATION

<Vehicles for Federal>




<Vehicles for California>



Removal steps

- 1 Heated oxygen sensor
- 2 Front catalytic converter
- 3 Front exhaust pipe

- 4 Rear catalytic converter
- 5 Heated oxygen sensor

**REMOVAL SERVICE POINT**

◄A► HEATED OXYGEN SENSOR REMOVAL

INSTALLATION SERVICE POINT

►A◄ HEATED OXYGEN SENSOR REMOVAL

INSPECTION

77-2000000

Inspect for damage, cracking or deterioration. Replace if faulty.


Caution

1. Stop the engine immediately if engine misfiring occurs, otherwise an abnormally hot exhaust system will damage the catalytic converter or other underbody parts.
2. Correct and repair the ignition or fuel system if there are malfunctions, otherwise engine misfiring may occur which will damage the catalytic converter.
3. Observe manufacturer's specifications when doing service work.

EVAPORATIVE EMISSION CANISTER/AIR FILTER/EVAPORATIVE VENTILATION SOLENOID

1.7.200400/11

REMOVAL AND INSTALLATION

**Removal steps**

- | | | | |
|----|--|----|---|
| 1 | Leveling air connection | 11 | Evaporative emission ventilation solenoid |
| 2 | Purge hose connection | 12 | Vent hose B |
| 3 | Vent pipe | 13 | Vent valve |
| 4 | Canister bracket | 14 | Vent hose C |
| 5 | Canister upper cover | 15 | Vent hose D |
| 6 | Vent hose A | 16 | Air filter |
| 7 | Plug hose | 17 | Vent hose E |
| 8 | Purge pipe assembly | 18 | Canister lower cover |
| 9 | Vapor hose | | |
| 10 | Evaporative emission canister assembly | | |



Fig. 11-1

INSPECTION

1/30086C181

EVAPORATIVE EMISSION VENTILATION SOLENOID CHECK

- (1) Connect a hand vacuum pump to nipple (A) of the solenoid.
- (2) Check airtightness by applying a vacuum with voltage applied directly from the battery to the evaporative emission ventilation solenoid and without applying voltage.




Fig. 11-2

Battery voltage

Normal condition

Applied

Vacuum maintained

Not applied

Vacuum leaks

- (3) Measure the resistance between the terminals of the solenoid.

Standard value: 17 - 21 Ω [at 20° C (68° F)]