



Handbook

Expert Tepee






PRESENTATION

This handbook is designed to familiarise you with the new vehicle from the moment you get behind the wheel and to describe the operating features.

Reading the handbook is made easy by a content consisting of 10 identified chapters which can be located by means of a colour code specific to each one. Its sections cover, by theme, all of the functions of the vehicle in its most complete specification.

Chapter 8 indicates all of the technical data relating to your vehicle. At the end of the document, diagrams of the outside and inside of the vehicle will assist you in locating equipment or functions and page numbers refer you to the relevant section of the handbook.

Within the chapters symbols draw your attention to specific information:

-  directs you to the chapter and section which contains detailed information concerning a function,
-  indicates important information relating to use of the equipment,
-  alerts you to the safety of individuals and equipment on board.

PEUGEOT COMMUNICATION PUTS AN INTERNET SITE AT YOUR DISPOSAL



The technical data, equipment and accessories may change during the year. To obtain this new data, refer to the "Latest Information" section on the SERVICE BOX Internet site free of charge.

<http://public.servicebox.peugeot.com>, select:

- your model,
- the body type: saloon, CC, SW, estate, van...,
- the period corresponding to the date of first registration,
- the "Latest Information" section.

Key - Remote control

Complete locking of the vehicle, cab and rear doors.
Complete unlocking of the vehicle, cab and rear doors.



2a ▶ 17



Door open warning light

If this comes on, a door has not been closed correctly.

Sliding side door

Pull the handle towards you then towards the rear and open the door guiding the rearward sliding until the point of resistance has been passed.
If fitted on your vehicle, do not open the left-hand side door while filling with fuel as this could damage the fuel filler flap.



2b ▶ 22

Usable dimensions



8 ▶ 136

Key

● : chapter identification

▶ : page identification

Exterior

Hinged rear doors

This control permits opening to approximately 180°.



2 ▶ 23

Rear suspension

Two functions:

- Automatic correction.
- Manual correction.



3a ▶ 79

Parking assistance

In bad weather or in winter, check that the sensors are not covered with mud, ice or snow.



3b ▶ 86



Repairing a wheel




7 ▶ 117

Changing a wheel



7 ▶ 118



Opening the bonnet

Lift the cover at the foot of the left-hand seat and pull the control upwards.




Partially open the bonnet, lift the control and raise the bonnet.



Secure the strut in one of the two notches, according to the height required, to hold the bonnet open.


6 ▶ 106



Towing eye

At the front, unclip the cover by pressing it at the bottom.
At the rear, unclip the cover using a coin or the flat part of the towing eye.


7 ▶ 133



Diesel engines

Take care when working under the bonnet.
Refer to the "Levels" section of chapter 6 for advice on use of the fluids.

6 ▶ 107



Petrol engine


6 ▶ 108

Interior



INSTRUMENTS AND CONTROLS

1. Lights and direction indicators stalk.
2. Instrument panel with display.
3. Wipers, wash-wipe, trip computer controls.
4. Gear lever.
5. Ignition.
6. Audio equipment controls.
7. Driver's air bag, horn.
8. Steering wheel height and depth adjustment.
9. Headlamp beam adjustment.
10. Cruise control, speed limiter switch.
11. 12 volt accessories socket (120 W max) of the lighter type.
12. Ashtray.
13. Glove box, auxiliary socket, passenger air bag disarming switch.



1257 ADJUSTING THE TIME

Depending on the configuration of your vehicle, you have either:

- a centre console with display: refer to the "Adjusting the date and time" section of chapter 9,
- a centre console without display: refer to the "Instruments and controls" section of chapter 2.

CENTRE CONSOLE AND OVERHEAD STORAGE UNIT

1. Location of the controls:
 - locking of the electric child lock,
 - central locking/unlocking.
2. Heating and/or air conditioning controls.
3. Location of the ticket/card storage or controls:
 - deactivation of the ESP,
 - disarming of the interior protection alarm, alarm diode,
 - deactivation of the parking assistance.
4. CD changer or storage compartment.
5. Audio equipment or storage compartment.
6. Central adjustable vents.
7. Hazard warning lights button.
8. Display or storage compartment.
9. Courtesy light.
10. Passenger air bag disarmed warning light.
11. Location of the ticket/card storage, rear ventilation deactivation switch, heated seat controls.

SIT COMFORTABLY

10



1. Forwards-backwards adjustment.



2. Angle.



3. Height.



4. Lumbar.



5. Head restraint height.



Steering wheel

Adjust the height and depth of the steering wheel.

2 ▶ 35



Mirrors

Manual adjustments.



Electric windows

3 ▶ 84



Seat belts

Height adjustment.
Fastening.

4 ▶ 89



Electric adjustments, electric folding/
unfolding.

3 ▶ 82

SEE CLEARLY

12



Lights stalk



Lights off.



Side lights.



Main beam headlamps (blue).




Dipped headlamps (green).

AUTO

AUTO, automatic switching on of the lights.

3 ▶ 37



Wipers stalk

- 2 fast.
- 1 normal.
- I intermittent.
- 0 off.
- ↵ single wipe.



AUTO, press the stalk down.

3 ▶ 40



Changing bulbs

In bad weather or in winter, check that the lights are not covered with mud or snow.

7 ▶ 123

DRIVE SAFELY



PC Com

This audio equipment incorporates a hard disc with a capacity of 10 Gb, reserved for your music.

The Jukebox function permits the selective playing of up to 10 hours of music. The detailed map of Europe is stored on this hard disc, without the addition of a CD. It is displayed on the 16/9ths 7" colour display and offers a 3D view.

Via your SIM card, the GSM hands-free telephone also provides access to the PEUGEOT emergency team (subject to conditions).

9



PC Sound

9



PC Nav

This ergonomic audio equipment offers a map of Europe on SD Card, a Bluetooth telephone connection and the playing of MP3/WMA files.

9



Cruise control

The vehicle speed must be higher than 25 mph (40 km/h) with at least 4th gear engaged.

3 ▶ 42



Speed limiter

The lowest speed which can be programmed is 20 mph (30 km/h).

3 ▶ 45

CAB LAYOUT

14



Overhead storage unit

3 ▶ 74



Glove box

3 ▶ 72



Storage compartment


3 ▶ 72

REAR LAYOUT



Rear seats

3 ▶ 64



Seating area layout

3 ▶ 76

CHILD SAFETY



Configurations of the seats/bench seats

3 ▶ 71



Electric child lock

2 ▶ 22



Monitoring mirror

3 ▶ 83



Rear windows

3 ▶ 83



Safety auto-reverse

3 ▶ 84



Child seats

4 ▶ 96

VENTILATION

16



Manual


3 ▶ 48



Automatic, with separate driver and passenger settings

3 ▶ 50

Recommended settings					
For optimum use of the system, we recommend:					
If I require...	Air distribution	Temperature	Air flow	Air recirculation	AC
Heating					-
Cooling					A/C
De-icing Demisting					



Rear

3 ▶ 56