

DEPARTMENT OF THE ARMY
SUPPLY CATALOG

ORD 9 SNL G-503

Group G

LIST OF ALL SERVICE PARTS

FOR

TRUCK, $\frac{1}{4}$ TON, 4x4, COMMAND RECONNAISSANCE
(FORD; MODEL GPW; WILLYS; MODEL MB)


Supersedes ORD 9 SNL G-503, 15 February 1945

Ref: TM 9-1803A

TM 9-1803B

This pamphlet is correct to 23 August 1949

G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep




Motor

G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep

Key	ITEM	Part No	IMP-No	Key	ITEM	Part No	IMP-No
1	Screw	WG-214333	450101	83	Grease	WG-630727	450183
2	Washer	WG-120282	45004	84	Washer	WG-84796	450184
3	Elbow	WG-70029	450103	85	Crankshaft	WG-638121	450185a
4	Gasket	WG-639650	450104	85	Crankshaft	WG-638121	450185g
5	Thermocast	WG-637846	450105	86	Bolt	WG-632457	450186
6	Retainer	WG-639651	450106	87	Bolt	WG-632157	450187
7	Nut	WG-630030	450061	88	Nut	WG-22542	450047
8	Head	WG-A1834	450108	89	Washer	WG-52930	45004
9	Gasket	WG-639678	450109	90	Bearing	WG-639678	450190
10	Stud	WG-349268	450110	90	Bearing	WG-639678	450190a
11	Stud	WG-A1548	450111	91	Flywheel	WG-A1443	450191
12	Block	WG-A1272	450112	92	Gear	WG-635384	450192
13	Gasket	WG-637062	450113	93	Seal	WG-637780	450193
14	Screw	WG-51958	450073	94	Mainbearing	WG-645182	450194a
15	Washer	WG-61033	450116	94	Mainbearing	WG-645182	450194b
16	Screw	WG-A6428	450117	94	Mainbearing	WG-645182	450194c
17	Drain	WG-A1126	450118	94	Mainbearing	WG-645182	450194d
18	Stud	WG-348712	450118	94	Mainbearing	WG-645182	450194e
19	Stud	WG-632158	450118	94	Mainbearing	WG-645182	450194f
20	Knud	WG-300143	450120	100	Flashing	WG-637237	450194i
21	Gasket	WG-638480	450121	102	Gasket	WG-639680	4501102
22	Housing	WG-A428	450122	103	Pin	WG-A1329	4501103
24	Plate	WG-A5121	450124	104	Screw	WG-120228	4501104
25	Screw	WG-6606	450125	106	Washer	WG-120214	45002
27	Washer	WG-62428	45004	106	Plug	WG-639978	4501106
28	Nut	WG-62542	450047	107	Washer	WG-640030	4501107
29	Washer	WG-5010	45004	108	Flwd	WG-630288	4501108
30	Screw	WG-630101	450120	109	Shield	WG-A1124	4501109
31	Screw	WG-52379	450131	110	Spacer	WG-A1126	4501110
32	Nut	WG-62542	450047	111	Gasket	WG-638398	4501111
33	Stud	WG-3758981	450138	112	Support	WG-630297	4501112
34	Washer	WG-61823	45003	113	Clamp	WG-A5105	4501113
35	Nut	WG-A1532	450037	114	Fltar	WG-65915	4501114
36	Plug	WG-219187	450138	116	Gasket	WG-7258	4501116
37	Gasket	WG-638737	450137	118	Diplatek	WG-A5525	4501118
38	Screw	WG-6428	450138	117	Ring	WG-632864	4501117a
39	Washer	WG-61823	45003	117	Ring	WG-632864	4501117b
40	Rooring	WG-639051	450140	117	Ring	WG-632864	4501117c
41	Insulator	WG-A7498	450141	117	Ring	WG-632864	4501117d
42	Washer	WG-120284	45006	117	Ring	WG-632864	4501117e
43	Nut	WG-637069	450061	117	Ring	WG-632864	4501117f
44	Gasket	WG-63058	450144	117	Ring	WG-632864	4501117g
45	Plate	WG-A1482	450146	120	Pinion	WG-613695a	4501120a
46	Gasket	WG-630385	450147	120	Pinion	WG-613695a	4501120b
47	Cover	WG-A1190	450148	120	Pinion	WG-613695a	4501120c
48	Screw	WG-6412	450148	120	Pinion	WG-613695a	4501120d
49	Screw	WG-50183	45004	120	Pinion	WG-613695a	4501120e
50	Washer	WG-5010	450047	120	Pinion	WG-613695a	4501120f
51	Nut	WG-62542	450047	122	Node	WG-640071	4501122
52	Valve	WG-637183	450182a	123	Washer	WG-5010	45004
52a	Valve	WG-627183	450182a	124	Screw	WG-632157	4501124
53	Spring	WG-6378236	450183	126	Bolt	WG-640070	4501126
54	Retainer	WG-637044	450184	126	Nut	WG-639682	4501126
55	Lock	WG-376894	450186	127	Nut	WG-62825	4501127
56	Screw	WG-640020	450187	128	Rollbearing	WG-639862	4501128a
57	Tapert	WG-637047	450188	128	Rollbearing	WG-639862	4501128b
58	Clude	WG-118137	450189	128	Rollbearing	WG-639862	4501128c
59	Clude	WG-118138	450189	128	Rollbearing	WG-639862	4501128d
60	Line	WG-A1450	450181	128	Rollbearing	WG-639862	4501128e
61	line	WG-A1108	450182	128	Rollbearing	WG-639862	4501128f
62	Elbow	WG-384568	450182	128	Rollbearing	WG-639862	4501128g
63	Crankshaft	WG-641284A	450183	128	Rollbearing	WG-639862	4501128h
63	Crankshaft	WG-637065	450183a	130	Gasket	WG-630305	4501130
64	Spacer	WG-641049J	450184	131	Cover	WG-630303	4501131
65	Gear	WG-641283B	450185	132	Valve	WG-A8996	4501132
66	Gear	WG-641283B	450185a	133	Elbow	WG-A8996	4501133
67	Chain	WG-639457	450188	134	Line	WG-A8922	4501134
68	Washer	WG-128857	45004	135	Ring	WG-61875	4501135
69	Screw	WG-122260	450188	136	Bolt	WG-639652	4501136
70	Spring	WG-376909	450170	137	Elbow	WG-384549	4501137
71	Line	WG-A6918	450171	138	Ventilator	WG-A6919	4501138
72	Ball	WG-A8490	450172	139	Gasket	WG-630288	4501139
73	Key	WG-124549	450173	140	Ball	WG-630288	4501140
74	Nut	WG-287833	450174	141	Bolt	WG-632158	4501141
75	Pully	WG-638113	450175	144	Jointion	WG-37633	4501142
76	Pully	WG-638113	450175a	147	Plug	WG-102595	4501147
76	Gasket	WG-334103	450176	140	Screw	WG-A171800	4501148
77	Ring	WG-637098	450177	148	Bolt	WG-120007	4501149
78	Washer	WG-37820	450178	150	Washer	WG-120214	45002
79	Spacer	WG-378277	450179	161	Pin	WG-638377	4501151
80	Gasket	WG-334103	450180	162	Part of block		4501152
81	Gear	WG-638459	450181	163	Part of block		4501153
81	Gear	WG-638459	450181a	164	Part of block		4501154
82	Key	WG-124552	450182	165	Gasket set		4501155


G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep



Key	ITEM	Part No	M&P-No
1	Plug	WO-630390	450201
2	Ring	WO-634813	450202
3	Plate	WO-630389	450203
4	Spring	WO-656155	450204
5	Plunger	WO-630518	450205
6	Screw	WO-51819	450206
7	Washer	WO-380197	450207
8	Cover	WO-630387	450208
9	Plug	WO-52525	450209
10	Gear	WO-343306	450210
11	Plate	WO-636600	450211
12	Drive	WO-636599	450212
13	Ring	WO-375927	450213
14	Gasket	WO-639870	450214
15	Housing	WO-630384	450215
16	Gear	WO-637425	450216
17	Pin	WO-336964	450217
18	Gasket	WO-630394	450218
19	Oil pump assy	WO-641046	450219
20	Oil pump assy	WO-637636	450220
21	Oil pump rep kit	WO-70089	450221
22	Oil pump rep kit	WO-70089	450222

Oil pump
Page 2


G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep



Key	ITEM	Part No	N&P-No
1	Bolt	WO-A1232	450301
2	Gasket	WO-A1233	450302
3	Cover	Wo-A1231	450303
4	Spring	Wo-A1234	450304
5	Gasket	Wo-A1235	450305
6	Bracket	Wo-A1247	450306
7	Clamp. assy	Wo-A1251	450307
8	Element,assy	Wo-A1236	450308
9	Elbow	Wo-384569	450309
10	Connector	Wo-387891	450310
11	Line, assy	Wo-A1197	450311
12	Case,assy	Wo-A6818	450312
15	Plug	Wo-A1237	450315
16	Line, assy	Wo-A1198	450161
17	Filter assy	Wo-70089	450317


Oil filter
Page 3

G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep




Key	ITEM	Part No	N&P-No
1	Bail, assy	WO-115657	450401
2	Seat	WO-113460	450402
3	Bowl	WO-A1494	450403
4	Screen	WO-115654	450404
5	Gasket	WO-115656	450405
6	Cover	WO-115650	450406
7	Line	WO-116552	450407
8	Elbow	WO-116500	450408
9	Diaphragm,assy	WO-116995	450409
10	Clamp	WO-115653	450410
11	Valve,assy	WO-115651	450411
12	Screw	1329696	450412
13	Gasket	AC-1537404	450413
14	Spring	WO-116694	450414
15	Washer	WO-115869	450415
16	Seal	WO-115870	450416
17	Spring	WO-115643	450417
18	Arm	WO-115641	450418
19	Link	WO-115880	450419
20	Pin	WO-A1046	450420
21	Body assy	WO-A1045	450421
24	Fuel pump assy	WO-A1437	450424
25	Fuel pump Rep.Kit	WO-A1458	450425

G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep




Key	ITEM	Part No	M&P-No
1	Screw	WO-853634	450501
2	Gasket	WO-A1257	450502
3	Cover	WO-A1258	450503
4	Line	WO-A1366	450504
5	Line	WO-A1367	450505
6	Fitting	G119922	450506
7	Hose	WO-A1325	450507
8	Element	WO-1595823	450508
9	Spring	WO-1504118	450509
10	Bowl	WO-A1263	450510
11	Plug	WO-127951	450511
12	Gasket	WO-A1260	450512
13	Gasket	WO-A1259	450513
14	Plug	WO-103866	450514

G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep




Key	ITEM	Part No	NAP-No
1	Lever	WO-116545	450601
2	Nut	WO-116219	450602
3	Clamp	WO-116587	450603
4	Screw	WO-116588	450604
5	Spring	WO-116189	450605
6	Lever	WO-116586	450606
7	Spring	WO-116184	450607
8	Screw	WO-116211	450608
9	Valve	WO-116157	450609
12	Screw	WO-116385	450612
13	Rod	WO-116540	450613
14	Cover	WO-116208	450614
16	Screw	WO-116213	450615
16	Washer	WO-6330	450616
17	Pin	WO-116173	450617
18	Die	WO-116206	450618
19	Valve	WO-116174	450619
20	Spring	WO-116191	450620
21	Pin	WO-116177	450621
22	Plug	WO-116165	450622
23	Gasket	WO-116169	450623
24	Jet	WO-116539	450624
25	Gasket	WO-116203	450625
26	Float	WO-116172	450626
27	Jet	WO-116541	450627
28	Gasket	WO-116171	450628
29	Nozzle	WO-116166	450629
30	Plug	WO-116161	450630
31	Plug	WO-116164	450631
32	Rod	WO-116198	450632
33	Spring	WO-116185	450633
34	Retainer	WO-116194	450634
35	Arm	WO-116197	450635
36	Screw	WO-52290	450636
38	Flange	WO-116584	450638
39	Valve	WO-116164	450639
40	Screw	WO-116217	450640
41	Shaft	WO-116585	450641
42	Screw	WO-116214	450642
43	Spring	WO-116183	450643
44	Screw	WO-116176	450644
45	Gasket	WO-116202	450645
46	Insulator	WO-116210	450646
47	Plug	WO-116163	450647
48	Gasket	WO-116170	450648
49	Strainer	WO-116175	450649
50	Check,assy	WO-116205	450650
51	Check,assy	WO-116204	450651
52	Washer	WO-6045	450652
53	Screw	WO-116216	450653
54	Jet	WO-116180	450654
55	Plug	WO-116164	450655
56	Spring	WO-116188	450656
57	Plunger	WO-116195	450657
58	Pin	WO-116173	450658
59	Link	WO-116199	450659
60	Spring	WO-116187	450660
61	Lever	WO-116637	450661
62	Spring	WO-116178	450662
63	Pin	WO-116209	450663
64	Spring	WO-116538	450664
65	Washer	WO-116207	450665
66	Nut	WO-52616	450666
67	Arm	WO-116181	450667
68	Screw	WO-116394	450668
69	Link	WO-116542	450669
70	Carb. assy	WO-116181	450670
71	Rep. kit	WO-116384	450671
72	Carb. assy	WO-116543	450672

G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep




Key	TERM	Part No	N&P-No
1	Gasket	WO-A70089	450701
2	Extension	WO-A6424	450702
3	Strap, assy	WO-A1477	450703
4	Nut	WO-52891	45003c
5	Nut	WO-A1532	45003c
6	Bolt	WO-A1483	450706
7	Cap, assy	WO-A6333	450707
8	Strap, assy	WO-A1472	450708
8a	Strap, assy	WO-A1472	450708a
9	Tank, assy	WO-A6618	450709
10	Protector	WO-A1763	450710
11	Screw	WO-5556	450711
12	Gasket	WO-A1293	450712
13	Plug	WO-A5120	450713
14	Unit, assy 6V	WO-A1292	450714

G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep




Key	ITEM	Part No	N&P-No
1	Screw	WO-5272	450801
2	Nut	WO-632159	450802
3	Key	WO-637211	450803
4	Spring	WO-637208	450804
5	Nut	WO-52542	450805
6	Stud	WO-332515	450806
7	Shaft	WO-63706	450807
8	Stop	WO-6397430	450808
9	Manifold	WO-A1166	450809
10	Washer	WO-52428	45003
11	Bolt	WO-51486	450811
12	Washer	WO-637209	450812
13	Lever	WO-637210	450813
14	Plug	WO-5138	450814
15	Gasket	WO-634811	450815
16	Manifold	WO-A912	450816
17	Gasket	WO-A6357	450817
18	Nut	WO-50922	450041
19	Clip	WO-A1173	450819
20	Stud	WO-632159	450820

Manifolds and heat control




Key	ITEM	Part No	N&P-No
1	Pulley	WO-636299	4508a1
2	Bearing	WO-636297	4508a2
3	Body	WO-637052	4508a3
4	Spring	WO-636298	4508a4
5	Washer	WO-640034	4508a5
6	Seal	WO-640031	4508a6
7	Impeller	WO-639993	4508a7
8	Gasket	WO-637053	4508a8
9	Fan	WO-A447	4508a9
10	W. p. assy	WO-639992	4508a10
11	Rep. kit	WO-A6839	4508a11

G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep




Key	ITEM	Part No	N&P-No
1	Nut	WO-5910	45004c
2	Washer	WO-A51833	45004
3	Radiator assy	WO-A1214	450903
4	Hose	WO-A6373	450904
5	Drain	WO-A1126	450905
6	Pipe	WO-636109	450906
7	Cap	WO-A1215	450907
8	Gasket	WO-A1216	450911
9	Pipe	WO-6374	450909
10	Clamp	WO-52226	450910
11	Hose	WO-A6373	450904
12	Hose	WO-A6373	450904
13	Pin	WO-A1217	450913

G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep



Key	ITEM	Part No	N&P-No
1	Hose	WO-A1311	451001
2	Clamp	WO-635097	451002
3	Tube assy	WO-A6911	451003
4/5/8/9	Screw,Nut	WO-A1532	451004
6/7	Bracket L	WO-A1278	451006
10	Horn	WO-A463	451010
11	Clamp	WO-A1515	451011
12	Bushing	WO-A1451	451012
13	Bracket R	WO-A1279	451013
14/16	Body	WO-A5629	451014
15	Element	WO-A5630	451015
17/18	Gasket	WO-A5632	451017


G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep



Key	ITEM	Part No	MRP-No
1	Cap	WO-A1655	451101
2	Rotor	WO-A1658	451102
3	Screw	WO-A1636	451103
4	Washer	WO-52754	451104
5	Point	WO-A1687	451105
6	Clip	WO-A1663	451106
7	Washer	WO-A1667	451107
8	Screw	WO-A1633	451108
9	Washer	WO-5168	451109
10	Screw	WO-A1686	451110
11	Cover	WO-A1660	451111
12	Spring	WO-A1677	451112
13	Weight	WO-A1676	451113
14	Rivet	WO-A1683	451114
15	Cup	WO-107128	451115
16	Shaft	WO-A1678	451116
17	Pin	WO-A1685	451117
18	Screw	WO-A1636	451118
19	Washer	WO-52221	451119
20	Screw	WO-A1670	451120
21	Capacitor	WO-A1631	451121
22	Plate	WO-A1664	451122
23	Spacer	WO-A1672	451123
24	Spring	WO-A1684	451124
25	Plate	WO-A1661	451125
26	Spring	WO-A1684	451126
27	Spacer	WO-A1672	451127
28	Washer	WO-A1673	451128
29	Clip	WO-A1682	451129
30	Base	WO-A1679	451130
31	Washer	WO-106740	451131
32	Ring	WO-A1659	451132
33	Washer	WO-A1654	451133
34	Arm	WO-A1674	451134
35	Distributor	WO-A70089	451135
36	Distributor. kit	WO-A70089	451136


Distributor, open type
Page 11

G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep



Key	ITEM	Part No	N&P-No	Key	ITEM	Part No	N&P-No
1	Band	WO-109452	451201	19	Screw	WO-A1559	451219
2	Head	WO-A1566	451202	20	Screw	WO-A1579	451220
3	Brush	WO-109446	451203	21	Washer	WO-A1574	451221
4	Washer	WO-109455	451204	22	Shaft	WO-A1581	451222
5	Insulator	WO-A1557	451205	23	Housing	WO-A1585	451223
6	Brush	WO-109431	451203	24	Screw	WO-A1589	451224
7	Coil	WO-109428	451207	25	Spring	WO-A1577	451225
8	Terminal	WO-A1554	451208	26	Screw	WO-A1578	451226
9	Post	WO-109433	451209	27	Head	WO-A1576	451227
10	Insulator	WO-109437	451210	28	Bearing	WO-A1582	451228
11	Coil	WO-A1560	451211	29	Coil	WO-109428	451229
12	Pole	WO-A1556	451212	30	Key	WO-5017	451230
13	Coil	WO-A1563	451213	31	Holder	WO-109442	451231
14	Connector	WO-A1558	451214	32	Spring	WO-109445	451232
15	Washer	WO-5437	451215	33	Screw	WO-1572	451233
16	Nut	WO-A1565	451216	34	Armature	WO-A1568	451234
17	Insulator	WO-A1553	451217	35	Starter 6V	WO-A1245	451235
18	Insulator	WO-109436	451218	36	Bushing	WO-10246	451236

G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep




Key	ITEM	Part No	N&P-No	Key	ITEM	Part No	N&P-No
1	Band	WO-A1649	451301	27	Insulator	WO-A1599	451327
2	Screw	WO-A7802	451302	28	Insulator	WO-A1598	451328
3	Cover	WO-A1626	451303	29	Screw	WO-A6297	451329
4	Gasket	WO-A1625	451304	30	Screw	WO-A1618	451330
5	Screw	WO-A1623	451305	31	Insulator	WO-A1594	451331
6	Washer	WO-52706	451306	33	Pin	WO-A1609	451333
7	Washer	WO-A1621	451307	34	Head	WO-A6300	451334
8	Bearing	WO-A6299	451308	35	Pulley	WO-A1639	451335
9	Washer	WO-A1624	451309	36	Washer	WO-A1639	451336
10	Head	WO-A6298	451310	37	Nut	WO-A1640	451337
11	Terminal	WO-A1608	451311	38	Washer	WO-A1646	451338
12	Post	WO-A1605	451312	39	Washer	WO-A1622	451339
13	Insulator	WO-A1595	451313	40	Washer	WO-A1644	451340
14	Pole	WO-A1600	451314	41	Retainer	WO-106313	451341
15	Pole	WO-A1600	451315	42	Screw	WO-A1647	451342
16	Coil	WO-A1604	451316	43	Screw	WO-52131	451343
17	Post	WO-A1602	451317	44	Key	WO-A1641	451344
18	Cable	WO-A1601	451318	45	Spring	WO-A1628	451345
19	Insulator	WO-01594	451319	46	Armatur	WO-A1637	451346
20	Nut	WO-A1611	451320	47	Screw	WO-A1596	451347
21	Washer	WO-A1616	451321	48	Insulator	WO-1592	451348
22	Nut	WO-A1617	451322	49	Nut	WO-52615	451349
23	Insulator	WO-A1597	451323	50	Arm	WO-A1629	451350
24	Washer	WO-A1615	451324	51	Brush	WO-A1630	451351
25	Insulator	WO-A1593	451325	52	Bolt	WO-A1590	451352
26	Insulator	WO-A1591	451326	53	Generator	WO-A1353	451353

Generator 6V bearing type

G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep




455070 Ident. Plate




Key	ITEM	Part No	NGP-No
A	Cover	WO-A9042	4514A
B	Nut	WO-A9040	4514B
C	Washer	WO-A9041	4514C
D	Regulator, assy	WO-A9049	4514D
E	Washer	WO-A9043	4514E
F	Washer	WO-A1616	4514F
G	Bracket, assy	WO-A7807	4514G
H	Screw	WO-A7803	4514H
J	Screw	WO-A8993	4514J
K	Washer	WO-A5262	4514K
L	Washer	WO-A1666	4514L
M	Screw	WO-A9050	4514M
N	Screw	WO-A1620	4514N
P	Regulator, assy	WO-A9051	4514P
Q	Insulator	WO-A7799	4514Q
R	Insulator	WO-A9048	4514R
S	Gasket	WO-A9047	4514S
T	Gasket	WO-A9046	4514T
U	Bracket, assy	WO-A7801	4514U
V	Bracket, assy	WO-A9044	4514V
W	Regulator, assy	WO-A1049	4514W

G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep




Key	ITEM	Part No	N&P - No
1	Lever	WO-638158	451501
2	Pin	WO-638159	451502
3	Spring	WO-638153	451503
5	Spring	WO-638993	451505
6	Screw	WO-638154	451506
7	Nut	WO-638155	451507
8	Washer	WO-638305	451508
9	Cup	WO-638157	451509
10	Cover	WO-638151	451510
11	Plate	WO-638152	451511
12	Facing	WO-636778	451512
13	Disk	WO-636755	451513
14	Facing	WO-371567	451514

G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep




Key	ITEM	Part No	M&P-No
1	Screw	WO-215368	451601
2	Washer	WO-116120	45003
3	Screw	WO-215417	451603
4	Padal	WO-A1360	451604
5	Arm	WO-A8253	451605
6	Shaft	WO-A495	451606
7	Arm	WO-A405	451607
8	Key	WO-124549	451608
9	Nut	WO-115729	45003c
10	Washer	WO-116120	45003
12	Nut	WO-118616	45005c
14	Pin	WO-108643	451614
15/16	Spring	WO-630593	451615
17	Cable	WO-A5102	451617
18	Stud	WO-A181	451618
19	Bracket	WO-A180	451619
20	Washer	WO-115314	45005
21	Pin	WO-7326118	451621
22	Spring	WO-A178	451622
23/24	Retainer	WO-A177	451623
25	Lever assy	WO-A1355	451625
26	Rod	WO-A499	451626

G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep




Key	ITEM	Part No	M&P-No
1	Carrier	WO-639654	451701
2	Bearing	WO-635529	451702
3	Spring	WO-630117	451703
4	Fork	WO-630112	451704
5	Ball	WO-630068	451705
6	Yoke	WO-632177	451706
7	Pin	WO-A177	451621
8	Nut	WO-364	45003f
9	Cable	WO-A5102	451617
10	Retainer	WO-640017	451710

G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep




Key	ITEM	Part No	N&P-No
1	Link	WO-A1175	451801
2	Spring	WO-633011	451802
3	Clip	WO-A1173	451803
4	Clamp	WO-639610	451804
5	Lever	WO-A1243	451805
6	Pin	WO-5433	451806
7	Stud	WO-337304	451807
8	Block	WO-633013	451808
9	Spring	WO-632174	451809
10	Bracket	WO-639607	451810
11	Washer	WO-52768	451811
12	Washer	WO-52706	45001
13	Nut	WO-5914	451813
14 + 17	Pedal	WO-A6710	451814
15	Nut	WO-5914	451815
16	Rest	WO-A1225	451816

G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep




Key	ITEM	PART No	M&P-No
1	Pipe assy	WO-A8101	451901
4	Insulator	WO-kit	451904
5	Bolt	WO-kit	451904
8	Strap	WO-kit	451904
9	Clamp	WO-kit	451904
10	Muffler assy	WO-A6118	451910
12	Clamp	WO-kit	451904
14	Clamp	WO-kit	451904
22	Clamp	WO-kit	451904
14/13/20	Screw	WO-kit	451904
21	Gasket	WO-2566	451921

G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep




G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep



Key	ITEM	Part No	N&P-No
A	Ring	WO-A945	4520M
B	Bearing	WO-A1434	4520M
C	Retainer	WO-A940	4520M
D	Yoke	WO-A935	4521D
E	Washer	WO-A943	4520E
F	Cap	WO-A942	4520F
G	Tube	WO-A1429	4521G
H	Yoke	WO-A1445	4520H
J	Nut	WO-121917	4520J
K	Strap	WO-70089	4520K
L	Bolt	WO-A490	4520L
M	Journal	WO-A1426	4520M
N	Yoke	WO-A950	4521N R
P	Shaft, assy	WO-A1327	4521P

Rear propeller shaft
Page 21


G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep



G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep

Key	ITEM	Part No	N&P-No	Key	ITEM	Part No	N&P-No
1	Screw	WO-A963	452301	38	Gasket	WO-A1509	452338
2	Fork	WO-A960	452302	39	Case	WO-A1503	452339
3	Gear	WO-A992	452303	40	Gear	WO-A1511	452340
4	Cup	WO-52883	452304	41	Shim	WO-A982,3,4	452341
5	Cone	WO-51575V	452304	42	Seal	WO-A958	452342
6	Gasket	WO-A957	452306	43	Cap assy	WO-A1507	452343
7	Interlock	WO-A965	452307	44	Bearing	WO-A985	452344
8	Shaft	WO-A962	452308	45	Gear	WO-A1512	452345
9	Shaft	WO-A1504	452309	46	Sleeve	WO-636396	452346
10	Bearing	WO-A1007	452310	47	Plug	WO-A1104	452347
11	Bearing	WO-A987	452311	48	Screw	WO-A963	452348
12	Shaft	WO-A975	452312	49	Fork	WO-A959	452349
13	Ring	WO-A976	452313	50	Plate	WO-A1001	452350
14	Housing	WO-A956	452314	51	Cone	WO-51575V	452304
15	Vent assy	WO-A934	452315	52	Cop	WO-A953	452304
16	Ball	WO-5599	452316	53	Plug	WO-5140	452353
17	Spring	WO-A966	452317	54	Gasket	WO-A954	452354
18	Plug	WO-A967	452318	55	Cover	WO-A953	452355
19	Seal	WO-A974	452319	56	Gear	WO-A988	452356
20	Knob	WO-A971	452320	57	Gear	WO-A1510	452357
21	Lever	WO-A1505	452321	58	Washer	WO-A1410	452358
22	Lever	WO-A1506	452322	59	Pin	WO-5134	452359
23	Spring	WO-A970	452323	60	Nut	WO-A520	452360
24	Screw	WO-A973	452324	61	Bearing	WO-17924	452361
25	Pin	WO-A972	452325	62	Shaft	WO-A998	452362
26	Yoke assy	WO-A1106	4520H	63	Washer	WO-A1000	452363
27	Washer	WO-A1028	452327	64	Gear	WO-A999	452364
28	Pin	WO-5134	452328	65	Washer	WO-A1000	452365
29	Nut	WO-A980	452329	66	Bearing	WO-A924	452366
30	Seal	WO-A958	452330	67	Shaft	WO-A1764	452367
31	Pin	WO-5134	452331	68	Gear	WO-A989	452368
32	Nut	WO-980	452332	69	Washer	WO-A990	452369
33	Flange	WO-A996	452333	70	Ring	WOA991	452370
34	Shield	WO-A1111	452334	71	Fitting	WO-638224	452371
35	Drum	WO-A1002	452335	72	Washer	WO-A410	452372
36	Washer	WO-A1028	452336	73	Plunger	WO-A1385	452373
37	Cover	WO-A1508	452337	74	Gasket set	GPW-18355	452374
				75	Gasket set	WO-70089	452375


G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep



Key	ITEM	PART No	N&T-No
1	Retainer	WO-640017	451710
2	Ring	WO-635844	452402
3	Ring	WO-635846	452403
4	Bearing	WO-636805	452404
5	Gear	WO-A5554	452405
6	Roller	WO-639422	452406
7	Gasket	WO-637495	452407
8	Case	WO-A1148	452408
9	Spring	WO-635837	452409
10	Ball	WO-635838	452410
11	Plate	WO-A7260	452411
12	Spring	WO-635839	452412
13	Ring	WO-637834	452413
14	Ring	WO-637831	452414
15	Sleeve	WO-637833	452415
16	Fork	WO-636196	452416
17	Screw	WO-636200	452417
18	Shaft	WO-A1155	452418
19	Pin	WO-635835	452419
20	Shaft	WO-A1156	452420
21	Screw	WO-636200	452421
22	Fork	WO-636197	452422
23	Gear	WO-636879	452423
24	Ring	WO-635844	452424
25	Spacer	WO-A15427	452425
26	Washer	WO-A410	452426
27	Ring	WO-637835	452427
28	Hub	WO-A6319	452428
29	Plate	WO-637832	452429
30	Hub	WO-637831	452430
31	Ring	WO-637834	452431
32	Gear	WO-638796	452432
33	Shaft	WO-A512	452433
34	Bearing	WO-A916	452434
35	Screw	WO-6428	452435
36	Washer	WO-G5029	45004
37	Washer	WO-635812	452437
38	Gear	WO-A8977	452438
39	Countershaft	WO-638948	452439
40	Bearing	WO-A878	452440
41	Plate	WO-638949	452441
42	Washer	WO-635811	452442
43	Washer	WO-A879	452443
44	Gasket	WO-635861	452444
45	Lever	WO-A1380	452445
46	Washer	WO-51833	45003
47	Screw	WO-6428	452447
48	Housing	WO-635857	452448
49	Spring	WO-392328	452449
50	Washer	WO-635863	452450
51	Cap	WO-A1379	452451
52	Plug	WO-5140	452453
53	Plug	WO-5140	452453
54	Spacer	WO-A880	452454
55	Gear	WO-636882	452455
56	Shaft	WO-638952	452456
57	Seal	WO-640018	452457
58	Knob	WO-A971	452458
60	Gasket set	GPW-18356B	452460


Transmission-exploded view
Page 24

G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep



Key	ITEM	Part No	N&P-No	Key	ITEM	Part No	N&P-No
1	Spring	WO-637905	4525a01	10	Lining	WO-116552	4525a08
2	Plate	WO-637901	4525a02	11	Shoe	WO-116550	4525a06
3	Eccentric	WO-A754	4525a03	12	Pin	WO-637899	4525a12
4	Washer	WO-5010	45004	13	Cam	WO-637900	4525a13
5	Nut	WO-52542	4525a05	14	Washer	WO-637923	45005
6	Shoe	WO-116549	4525a06	15	Nut	WO-5916	4525a15
7	Rivet	WO-70089	4525a07	16	Plate	WO-178898	4525a16
8	Lining	WO-116551	4525a08				


Wheel brake



Key	ITEM	Part No	N&P-No	Key	ITEM	Part No	N&P-No
1	Boot 1"	WO-637546	452501	5a	Cylinder 3/4"	WO-a1502	452505a
1a	Boot 3/4"	WO-637546	452501a	6	Cup 1"	WO-637579	452506
2	Piston	WO-637577	452502	6a	Cup 3/4"	WO-637579	452506a
3	Screw	WO-51738	452503	7	Screw	WO-637540	452507
4	Washer	WO-52483	45002	8	Spring	WO-637580	452508
5	Cylinder 1"	WO-a1502	452505				

Wheel cylinder


G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep



G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep


Key	ITEM	Part No	M&P-No
1	Line	WO-A1376	452701
2	Screw	WO-427238	452702
3	Screw	WO-5993	452507
4	Plate	WO-A8898	4525a16
5	Nut	WO-52542	4525a05
6	Screw	WO-A754	4525a03
7	Lever	WO-A1242	452707
8	Bracket	WO-A2892	452708
9	Bracket	WO-639010	452903
10	Screw	WO-51396	452710
11	Spring	WO-63568	452711
12	Handel	WO-639244	452712
13	Cap	WO-A1507	452713
14	Band	WO-A1009	452714
14a	Shoe	WO-A1009	452714a
15	Drum	WO-A1002	452335
16	Line	WO-A5226	452716
17	Line	WO-637424	452717
18	Bracket	WO-A5227	452718
19	Tee	WO-637432	452719
20	Line	WO-A5225	452720
21	Washer	WO-5010	45004
22	Screw	WO-A903	452722
23	Zylinder	WO-A6110	452723
24	Plate	WO-A8898	452516
25	Drum	WO-A4772	452725
26	Line	WO-A5224	452726
27	Nut	WO-5916	4525a15
28	Pin	WO-637899	4525a12
29	Line	WO-A1377	452729
30	Line	WO-A1375	452730
31	Line	WO-A1501	452731
32	Line	WO-A1460	452732
33	Line	WO-A1488	452733
34	Guard	WO-1457	452734
35	Clip	WO-637427	452735
36	Bolt	WO-637605	452815
37	Gasket	WO-637606	452812
38	Tee	WO-A557	452813
39	Zylinder	WO-637604	452811
40	Screw	WO-6157	451601
41	Arm	WO-A8253	451605
42	Pedal	WO-A1359	452742
43	Pin	WO-A1006	452743
44	Spring	WO-A5335	452744
45	Pin	WO-392468	452745
46	Rod	WO-A183	452746
47	Bracket	WO-640038	452747
48	Nut	WO-5939	452748
49	Plate	WO-A11354	452749

G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep




Key	ITEM	Part No	M&P-No
1	Boot	WO-637602	452801
2	Wire	WO-637598	452802
3	Plate	WO-637597	452803
4	Piston	WO-637591	452804
5	Cup	WO-637590	452805
6	Spring	WO-637587	452806
7	Valve	WO-637584	452807
8	Seat	WO-637583	452808
9	Cap	WO-637608	452809
10	Gasket	WO-637612	452810
11	Cylinder assy	WO-637582	452811
12	Gasket	WO-637504	452812
13	Fitting	WO-A557	452813
14	Gasket	WO-637606	452814
15	Bolt	WO-637605	452815
16	Switch	WO-A1271	452816
17	Rep. kit	WO-52446	452817
18	Bolt	WO-52836	452818

G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep




Key	ITEM	Part No	REF-No
1	Screw	WO-50929	45291
2	Cable	WO-A15149	45292
3	Bracket	WO-639010	45293
4	Nut	WO-A1532	45003c
5	Washer	WO-51833	45003
6	Washer	WO-A1533	45003
7	Clamp	WO-A1735	45297
8	Cable	WO-1241	45298

G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep



Steering gear



Drag link
Page 30

G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep


Key	ITEM	Part No	M&P-No
1	Housing	WO-A740	453101
2	Bushing	WO-639090	453102
3	Bushing	WO-939091	453103
4	Seal	WO-639095	453104
5	Plug	WO-5085	453105
6	Plug	WO-5085	453106
7	Shaft	WO-A8838	453107
8	Shaft	WO-A8838	453108
9	Ball	WO-639104	453109
10	Cup	WO-639102	453110
11	Shim	WO-639108	453111
12	Cover	WO-171760	453112
14	Jecket	WO-A1199	453114
15	Clamp	WO-A635	453115
16	Shaft	WO-A745	453116
17	Gasket	WO-639119	453117
18	Cover	WO-639116	453118
19	Scraw	WO-639118	453119
20	Nut	WO-52925	453120
21	Arm	WO-171116	453121
22	Nut	WO-639115	453122
23	Washer	WO-5038	453123
24	Beering	WO-639190	453124
25	Seat	WO-639192	453124
26	Spring	WO-639191	453126
27	Wheel MB	WO-A6858	453127
27a	Wheel M201	WO-A6858	453127a
28	Nut	WO-A633	453128
29	Tip	WO-A634	453138
30	Rod	WO-A750	453138
31	Ferrule	WO-A751	453138
32	Spring	WO-638884	453138
33	Cap	WO-63885	453138
35	Cable	WO-A752	453138
36	Ring	WO-A747	453136
37	Contact	WO-A70089	453137

Steering gear

Key	ITEM	Part No	M&P-No
1	Plug	WO-630756	4531a16
2	Seat	WO-630755	4531a16
3	Spring	WO-630754	4531a16
4	Plug	WO-630753	4531a16
5	Cover	WO-A622	4531a16
6	Shield	WO-A623	4531a16
7	Link	WO-A8252	4531a07
8	Fitting	WO-640038	4530010
9	Shield	WO-A623	4531a16
10	Cover	WO-A622	4531a16
11	Seat	WO-630755	4531a16
12	Seat	WO-630755	4531a16
13	Spring	WO-630754	4531a16
14	Plug	WO-630753	4531a16
15	Plug	WO-630757	4531a16
16	Drag link kit	WO-70089	4531a16
17	Drag link assy	WO-70089	4531a17


Drag link

G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep




Key	ITEM	Part No	N&P-No	Key	ITEM	Part No	N&P-No
1	Pin	WO-A1642	453201	21	Washer	WO-A867	453221
2	Nut	WO-10558	453202	22	Nut	WO-A866	453220
3	Nut	WO-GM117049	45004f	23	Shim	WO-A831	453223
4	Washer	WO-5010	45004	24a	Bendix	WO-A6030	453224a
5	Arm	WO-171712	453205	24b	Bendix	WO-A6030	453224b
6	Shim	WO-A6882	453206	27	End assy	WO-A847	453227
7	Stud	WO-A1714	453207	28	Nut	WO-52542	45004c
8	Knuckle	WO-A811	453208	29	Washer	WO-5010	45004
9	Plug	WO-5140	452353	30	Ring	WO-A1706	453230
10	Bushing	WO-A853	453210	31	Tube	WO-A1706	453311
11	Spindle	WO-A851	453211	32	Washer	WO-53029	45003
12	Washer	WO-5010	45004	33	Screw	WO-52132	453233
13	Screw	WO-A877	453213	34	Retainer	WO-A814	453234
14	Seal	WO-A864	453214	35	Screw	WO-A1707	453235
15	Cone	WO-52942	453215	36	felt	WO-A819	453236
16	Cup	WO-52943	453215	37	Strup	WO-A818	453237
17	Cup	WO-52943	453215	38	Retainer	WO-A814	453238
18	Cone	WO-52942	453215	39	Cup	WO-52941	453239
19	Washer	WO-A865	453219	40	Cone	WO-52940	453239
20	Nut	WO-A866	453220	41	Cap	WO-A828	453241

G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep



Key	ITEM	Part No	M&P-No
1	Housing	WO-A1703	453301
2r	Nut	WO-A476	453302r
2l	Nut	WO-A476	453302l
3	Seal	WO-A476	453303
4	Flange	WO-A868	453304
5	Washer	WO-636570	453305
6	Pin	WO-5134	452328
7	Nut	WO-636569	453307
8	Cap	WO-A869	453308
9	Screw	WO-A760	453309
10	Washer	WO-5010	45004
11	Tube	WO-A1705	453311
12	Bellcrank	WO-A8249	453312
13	End	WO-A838	453313
14	Tube	WO-A1709	453314
15	Clamp	WO-A1706	453230
16	Shaft	WO-A6272	453316
17	End	WO-A847	453227
18	Shaft	WO-173601	453318
19	Joint	WO-17367/8	453319
20	Shaft	WO-A369	453320
21	Screw	WO-1725	453321
22	Ball	WO-A1721	453322
23	Gage	WO-A1719	453323
24	Race	WO-A1720	453324
25	Pilot	WO-A1722	453325
26	Pin	WO-A1723	453326
27	Shaft	WO-A1727	453327
28	Ring	WO-A1726	453328
29	Retainer	WO-A1724	453329
30	Gasket set	GPW-18365-B	453330
31	Shim set	WO-A6881	453331


G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep



G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep

Key	ITEM	Part No	REP- No
1	Cup	WO-52881	453501
2	Cone	WO-52880	453501
3	Screw	WO-A871	453503
4	Strap	WO-A792	453504
5	Gasket	WO-A782	453505
6	Cover	WO-A10231	453506
7	Washer	WO-53029	45003
8	Screw	WD-51523	453508
9	Plug	WO-636577	453509
10	Plug	WO-636538	453510
11	Washer	WO-A795	453511
12	Gear	WO-A794	453512
13	Shaft	WO-A798	453513
14	Plug	WO-A870	453514
15	Pinion	WO-A796	453515
16	Washer	WO-A797	453516
17	Seal	WO-A779	453517
18	Shim	WO-A784	453518
19	Case	WO-A793	453519
20	Cone	WO-52880	453501
21	Cup	WO-52881	453501
22	Gear set	WO-A789	453522
23	Washer	WO-A797	453516
24	Gear	WO-A769	453524
25	Pin	WO-636380	453525
26	Gear	WO-A794	453512
27	Washer	WO-A795	453511
28	Seal	WO-A779	453517
29*	Shaft	WO-A901	453529*
29†	Shaft	WO-A901	453529†
30	Drum	WO-A472	452725
31†	Bolt	WO-A474	453531†
31†	Bolt	WO-A474	453531†
32	Nut	WO-A476	453302†
33	Gasket	WO-A904	453533
34	Washer	WO-5010	45004
35	Screw	WO-A760	453535
36	Cup	WO-A764	453536
37	Washer	WO-636528	453537
38	Screw	WO-636527	453538
39	Shim	WO-A800	453539
40	Spacer	WO-A799	453540
41	Shim	WO-A800	453541
42	Cup	WO-52877	453542
43	Cone	WO-52876	453542
44	Nut	WO-636375	45004†
45	Washer	WO-5010	45004
46	Screw	WO-A903	453546
47	Seal	WO-A854	453214
48	Cone	WO-52942	453215
49	Cup	WO-52943	453215
50	Cup	WO-52943	453215
51	Cone	WO-52942	453215
52	Washer	WO-A855	453219
53	Nut	WO-A856	453220
54	Washer	WO-A857	453221
55	Nut	WO-A858	453220
56	Pin	WO-636571	453556
57	Nut	WO-636569	453557
58	Washer	WO-636570	453558
59	Yoke	WO-A1445	4520H
60	Shield	WO-636558	453560
61	Seal	WO-639255	453561
62	Gasket	WO-636555	453562
63	Slinger	WO-636556	453563
64	Cone	WO-52878	453564
65	Cup	WO-52879	453564
66	Housing	WO-A888	453566
67	Gasket set	WO-A70089	453567

G503, 1/4 - TON; 4X4 Willys - MB, Ford - GPW, Jeep



453742 A Holz - Stoßstange

453755 Rahmenendstück hinten
453755 A Rahmen GPW neu

G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep

Key	ITEM	Part No	N&P-No
1	Member	WO-A547	453701
2	Member	WO-A1150	453702
3	Bracket	WO-A485	453703
4	Plate	WO-A1151	453704
5	Nut	WO-52542	453705
6	Washer	WO-5010	453706
7	Plate gearbox	WO-A146	453707
8	Silent	WO-A6157	453708
8a	Silent	WO-A6156	453708a
9	Plate	WO-A1253	453709
10	Nut	WO-A1532	453710
11	Washer	WO-51833	453711
12	Plate	WO-A1051	453712
13	Screw	WO-5934	453713
14	Member	WO-1203	453714
15	Gusset	WO-A544	453715
16	Gusset	WO-1128	453716
17	Gusset	WO-1127	453717
18	Gusset	WO-1129	453718
19	Bracket	WO-A1150	453720
20	Member	WO-A1150	453720
21	Washer	WO-5010	453721
22	Screw	WO-6412	453722
23	Bracket	WO-A657	453723
24	Nut	WO-52542	45004f
25	Washer	WO-5010	45004
26	Spacer	WO-A1680	453726
27	Crossmember	WO-A5127	453727
28	Washer	WO-A1680	453728
29	Cable	WO-A5125	453729
30	Fitting	WO-638792	450011
31	Bracket	WO-A500	453731
31a	Bracket	WO-A500	453731a
32	Bracket	WO-A1204	453732
40	Bracket	WO-A7498	450141
41	Bumper	WO-A481	453741
42	Bumper	WO-A1117	453742

G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep



Key	ITEM	Part No	M&P-No
1	Retainer	WO-A1252	453901
2	Seal	WO-A515	453902
3	Bolt	WO-574	453903
4	Bolt	WO-574	453903
5	Pin	WO-5021	453905
6	Nut	WO-6436	453906
7	bolt	WO-A6075	453907
8	Shackle	WO-A6068	453908
9	Spring	WO-A612	453909
10	Spring	WO-A6066	453910
11	Bushing	WO-A8255	453911
12	Bushing	WO-A8256	453912
13	Absorber	WO-A169	4541B
14	Absorber	WO-A169	4541D
15	Bushing	WO-637936	4541A
16	Fitting	WO-640038	450011
17	Bushing	WO-A6067	453917
18	Shackel	WO-A6069	453918
19	Bolt	WO-A	453919
20	Bolt	WO-A6511	453920
21	Plate	WO-A568	453921
23	Washer	WO-5038	45005
24	Nut	WO-339372	453924
25	Bolt	WO-116610	453925

Spring front left

Key	ITEM	Part No	M&P-No
1	U Bolt	WO-A574	453903
2	U Bolt	WO-A574	453903
3	Bushing	WO-359039	4539a3
4	Bolt	WO-384228	4539a4
5	U Bolt	WO-A514	4539a5
6	U Bolt	WO-A513	4539a6
7	Bushing	WO-A8255	453911
8	Bushing	WO-A8256	453912
9	Spring	WO-A15728	4539a9
10R	Plate	WO-A572	4539a21R
10L	Plate	WO-A571	4539a21L
11	Bolt	WO-116610	453925
12	Washer	WO-5938	45005
13	Nut	WO-339372	453924

Spring rear

G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep




G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep

Key	ITEM	Part No	REP-NO
A	Bushing	WO-637936	4541A
B	Absorber	WO-A169	4541B
C	Absorber	WO-A6902	4541B
D	Absorber	WO-A170	4541D
E	Absorber	WO-A6903	4541D

Shock absorbers assembly

Key	ITEM	Part No	REP-NO
A	Rim	WO-A5549	45410A
B	Beadlock	WO-520936	45410B
C	Tire	WO-511250	45410C
D	Disk	WO-A5468	45410D
E	Nut	WO-A5471	45410E
F	Tube	WO-519246	45410F
G	Bolt	WO-A5470	45410G


G503, 1/4 - TON, 4X4 Willys - MB; Ford - GPW, Jeep



Key	Titel	Part No	M&P-No
1	Glas	WO-A2478	454201
2	Frame	WO-A2226	454202
3	Frame assy	WO-A3210	454203
4	Switch	WO-A11866	454204
5	Clamp	WO-A2227	454205
6	Switch	WO-A0811	454206
7	Speedometer	WO-AB180	454207
8	Gage	WO-AB190	454208
9	Switch	WO-A1333	454209
10	Ammeter	WO-A6241	454210
11	Gage	WO-AB188	454211
12	Control	WO-A7617	454212
13	Control	WO-A7617	454213
14	Gage	WO-AB184	454214
15	Mirror	WO-A2934	454215
16	Arm	WO-A2235	454216
16a	Arm&Br.	WO-A2235	454216a
17	Handle	WO-639244	454217
18	Clamp	WO-A2227	454218
19	Lock	WO-A3436	454219
20	Glove	WO-A3835	454220
21	Lamp	WO-A1437	454221
22	Bolt	WO-70089	454222

Front compartment and instrument panel
Page 42

G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep





Key	ITEM	Part No	NLD-No	Key	ITEM	Part No	NLD-No
A	Apron	WO-A2842	4543A	W	Strap	WO-A3110	4543W
B	Loop	WO-A2234	4543B	X	Trim	WO-A2987	4543X
C	Catch	WO-A2896	4543C	Y	Trim	WO-A2985	4543Y
D	Catch	WO-A3197	4543D	Z	Pad	WO-A11732	4543Z
E	Fender	WO-A2943	4543E	Za	Pad	WO-A11732	4543Za
Ea	Fender	WO-A2943	4543Ea	AA	Bracket	WO-A2453	4543AA
F	Frame	WO-A3204	454203	BB	Lid	WO-A3227	4543BB
G	Step	WO-70089	4543G	CC	Spring	WO-A2830	4543CC
H	Bracket	WO-A2213	4543H	DD	Bow	WO-A2897	4543DD
J	Chain	WO-A2501	4543J	EE	Pad	WO-A3114	4543EE
K	Screw	214018	4543K	FF	Strap	WO-A2883	4543FF
L	Panel	WO-A12010	4543L	GG	Weatherstrip	WO-A2476	4543GG
M	Panel	WO-A12105	4543M	HH	Clamp	WO-A2227	454205
N	Cushion	WO-A11730	4543N	JJ	Glass	WO-A2478	454201
Na	Cushion	WO-A11730	4543Na	KK	Bumper	WO-A3780	4543KK
P	Panel	WO-A2757	4543P	LL	Light, assy	WO-A1304	4543LL
Q	Handel	WO-A2390	4543Q	MM	Light, assy	WO-A1436	4543MM
R	Bracket	WO-A2745	4543R	NN	Hood, assy	WO-A3225	4543NN
S	Reflector	CB-3121441	4543S	PP	Guard	WO-A3615	4543PP
T	Bracket	WO-A2754	4543T	QQ	Light, assy	WO-A1305	4543LL
U	Handel	WO-A2389	4543U	RR	Light, assy	WO-A1437	4543MM
V	Screw	WO-A2214	4543V				

G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep

Key	ITEM	Part No	M&P-No
A	Screw	214018	4544A
B	Screw	120050	4544B
C	Loop	WO-A2168	4544C
D	Spacer	7044154	4544D
E	Bracket, assy	WO-A2359	4544E
F	Nut	WO-A476	453302r
G	Handle	WO-A2389	4543U
H	Spacer	7044173	4544H
J	Reflector	CB-3121441	4544J
K	Light, asy	504413	4544K
L	Plate	WO-A2359	4544L


Spare wheel carrier



Key	ITEM	Part No	M&P-No
A	Nut	WO-5939	45440A
B	Washer	WO-52349	45005
C	Screw	WO-6923	45440C
D	Bolt	WO-A6393	45440D
E	Lock	WO-A593	45440E
F	Pin	HLH-T67	45440F
G	Latch	HLH-T63	45440G
H	Bolt	HLH-T64A	45440H
J	Washer	WO-5009	45005
K	Nut	WO-6163	45005c
L	Pintel assy		45440L

Pintel assembly
Page 44

G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep



455066
Kanister US

455057
Kanister Gurt

455130
Ausg. US-Kanister

455040
Wassersack

455066a
Kanister Halter

455040 Studs
455129 orig. Ford

455035
Achshalter vorne

451575 Halter
455016
Antennen-Stäbe

455032
Axt Klappbügel

Key	LT32M	Part No	M&P-No
1	Handel	WO-A2389	4543U
3	Pintel	WO-70089	45440L
4	Bumper	WO-A1157	454504
5	Top bow	WO-A2897	4543DD
7	Arm	WO-A2235	454507
8	Clamp	WO-A2227	454205
9	Catch	WO-A2896	4543C
10	Wingnut	WO-214018	4543K
12	Fender	WO-A2943	4543E
13	Handel	WO-A2390	4543Q
14	Light	WO-504413	4544K
15	Reflector	CB3121441	4544J

45015
Ohio brass

455036

455131
MP 50

55094
werkzeugtasche Leinen


455035
Axt

455132
Winkel

Body

455037
Andrehkurbel

G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep



ITEM	Part No	MLP-No
Arm, assy	7069271	454601
Collar	7069272	454602
Lock	7069274	454603
Connector, assy	5700003	454604
Crank, assy	7069273	454605
Blade	B209586C	454606

G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep

U.S.A. # 454701
20693359-S

Motorhaube



454703

Motorhaube und Seite

US-Farbe grün ● 455030

US-Farbe Ford GPW grau ● 455030a

US-Farbe mattschwarz ● 1100091

454702

11Δ **A**
15 **10**

Stoßstangen hinten

454704

11Δ - 15 / A 10

Stoßstange vorn



454705

Zeichen nach Vorlage

Beschriftung Windshieldcover



VEHICLE TRUCK-1/4TON 4X4


OVERALL LENGTH	121 IN
OVERALL WIDTH	62 IN
OVERALL HEIGHT	72 IN
LOWEST OPERABLE HEIGHT	52 IN
SHIPPING CUBIC	244 1/2
SHIPPING TONNAGE	8.11

Beschriftung Shipping Tonnage

454707



G503, 1/4 - TON, 4X4 Willys - MB, Ford - GPW, Jeep



IDENTIFICATION

TRAILER 2 WHEELS 1/4 TON	
SUPPLY ARM OR SERVICE	_____
MAINTAINING VEHICLE ORDNANCE DEPARTMENT	_____
MAKE AND MODEL	BANTAM-T 3
SERIAL NUMBER	_____
GROSS WEIGHT	1050 LBS.
MAXIMUM PAYLOAD	850 LBS.
MAXIMUM SPEED	53 MPH.
CUBIC CONTENT	10.4 CU FT.
DATE OF DELIVERY	_____
PUBLICATIONS APPLYING TO THIS TRAILER	
PARTS LIST T-MID-1201	
MAINTENANCE MANUAL T-MO-1201	
BANTAM	
AMERICAN BANTAM CAR CO.	
DULLES, VA.	

1/4 TON 2 WHEEL GOVERNMENT TRAILER





FIG. 13—WHEEL BEARINGS




FIG. 14—FRONT VIEW OF TRAILER




FIG. 15—REAR VIEW OF TRAILER

